

Updating CY8CKIT-042-BLE KitProg and CySmart USB Dongle Firmware – KBA96152

Question: CY8CKIT-042-BLE KitProg firmware and the CY5670 CySmart USB Dongle KitProg and device firmware shows out of date. How should I update the firmware on these boards?

Answer: To update the KitProg firmware on CY8CKIT-042-BLE Bluetooth Low Energy (BLE) Pioneer Kit baseboard and CY5670 CySmart USB Dongle (BLE Dongle), and the PRoC BLE device firmware on the BLE dongle, do the following:

CY8CKIT-042-BLE Pioneer Kit – KitProg Update

- 1. Connect the BLE Pioneer Kit Baseboard to your computer using the USB Standard-A to Mini-B cable provided.
- 2. Wait for driver enumeration to complete (you can "skip" the windows update as the drivers are locally installed on your PC), shown in Figure 1.





Figure 1. Driver Installation



3. Open <u>PSoC Programmer</u> and click to select the BLE Pioneer Kit Baseboard KitProg. **Note** If you have multiple Cypress kits with KitProg firmware connected, unplug other kits to ensure that you select the right kit.


When you connect to the BLE Pioneer Kit Baseboard, you may see the warning about programmer being out of date, as shown in Figure 2.

Figure 2. CY8CKIT-042-BLE Pioneer Kit - Programmer Out-of-Date



A similar warning is displayed in the PSoC Programmer window, as shown in Figure 3.

Figure 3. CY8CKIT-042-BLE Pioneer Kit - Programmer Out-of-Date



4. To upgrade the firmware, go to the **Utilities** tab and click **Upgrade Firmware**, as shown in Figure **4**.




Figure 4. Upgrade Firmware



5. Verify that KitProg has been updated to version 2.10 (or newer), as shown in Figure 5.

Figure 5. CY8CKIT-042-BLE Pioneer Kit KitProg Firmware Upgrade



You have successfully completed the KitProg firmware upgrade on the BLE Pioneer Kit.



CY5670 CySmart USB Dongle - KitProg Update

1. Plug the CySmart BLE Dongle into your PC's USB port, as shown in Figure 6.



Figure 6. CySmart USB Dongle


- 2. Wait for driver enumeration to complete (you can "skip" the windows update as the drivers are locally installed on your PC).
- 3. Open PSoC Programmer and click to select "KitProg/BLE..."

Note CySmart USB Dongle name starts with KitProg/BLE...If you have multiple CySmart USB Dongles connected to your computer, then unplug other dongles to ensure that you select the right dongle.

When you connect to the CySmart USB Dongle, you may see the following warning about programmer being out of date, as shown in Figure 7.



Figure 7. BLE Dongle - Programmer Out-of-Date



- 4. Go to the **Utilities** tab and click **Upgrade Firmware**.
- 5. Verify that KitProg has been updated to version 2.10 (or newer).
- 6. You have successfully completed the KitProg firmware upgrade on the CySmart BLE Dongle.

CY5670 CySmart USB Dongle - PRoC Firmware Update

- 1. Plug the CySmart BLE Dongle into your PC's USB port.
- 2. Connect to the BLE USB Dongle from the Port Selection window.
- 3. Select **File > File Load...** (or press F4).
- 4. Select the following file:

 C:\Program Files (x86)\Cypress\CY8CKIT-042-BLE Kit\1.0\Firmware\BLE Dongle\Hex Files\BLE_Dongle_CySmart.hex (or download the latest from www.cypress.com/CY8CKIT-042-BLE)
- 5. Select **File** > **Program** (or press F5).
- 6. Verify that programming of the CYBL10162-56LQXI device has completed successfully, as shown in Figure 8.






Figure 8. PRoC BLE Firmware Update

You have now successfully upgraded the BLE firmware on your CySmart BLE Dongle.



Related Categories:

Keywords: CY8CKIT-042-BLE, BLE Pioneer Kit, CY5670 CySmart, BLE Dongle, BLE, KitProg, CySmart

**

Product Family: [Type the ORACLE Family listed under section Attachment 2 - Product Divisions Financial Reporting Structure in Spec 00-00077. Multiple products can be selected]

Related Tags: [Select the Tags by clicking the checkbox associated to the Tags]

Clocks & Buffers Tags

Adapter	Algorithm	Bitmap	Buffer	☐ Bypass	☐ CLKMAKER
☐ CML	☐ CY3670	☐ CY3672	☐ CY3675	☐ CY36800	☐ Cascade
☐ Charge Pump	☐ Clock Tree	Clocks	☐ Clocks and Buffers	☐ ComLink	☐ Crystal Oscillators
☐ CyClock	☐ CyClockWizard	☐ CyberClocks	CyberClocks Online	☐ Cycle to Cycle	DCXO
☐ Delay	☐ Deterministic Jitter	☐ Differential	Divider	☐ Duty Cycle	☐ EMI
☐ Enhanced Performance	☐ Ent	☐ Entrant	☐ FNOM	☐ Factory	☐ Failsafe
☐ Fanout	☐ FastEdge	☐ Feedback	Field	Flexo	Frequency
☐ Frequency Margining	☐ Function Select	Generators	☐ Ground Bounce	□ НРВ	☐HSTL
☐ Hershey Kiss	☐ I2C	☐ IBIS Model	☐ Impedance	☐ Input	☐ InstaClock
☐ Inverted	☐ Jed	☐ Jedec	Jitter	LVCMOS	LVDS
LVPECL	Layout	Lexmark Profile	☐ Loop Bandwidth	☐ MoBL	☐ Modulation Rate
☐ Multiplier	□NZDB	☐ Non-Volatile Memory	□ОТР	☐ Offset	☐ Oscillator
Output	☐ Overvoltage	☐ PCI Express	☐ PLL	☐ PPM	☐ PREMIS
☐ Period	☐ Phase	☐ Phase Noise	☐ Power Supply Noise	☐ Program	☐ Programmable
☐ Propagation	☐ Pullability	RMS	Rambus	Random Jitter	Reference
☐ Rise Fall Time	RoboClock	Schematic	☐ Serial	☐ Signal Integrity	Skew
Socket	☐ Specialty Clocks	☐ Spread %	☐ Spread Aware	☐ Spread Profile	☐ Spread Spectrum
Synthesizer	☐ TCXO	☐ TIE	☐ Termination	☐ Thermal	Translator
Undervoltage	UniClock	Unit Interval	□ vco	☐ VCXO	☐ Volatile Memory
☐ Voltage Droop	□XCG	□XDR	□xo	☐ Xtal	□ZDB



Zepto												
Lighting & Power	Contro	l Tags										
☐ Board Layout ☐	Boost Re	egulator	Buck	Regulator	☐ CY3	261	☐ CY32	67	☐ CY3268			
☐ CY3269 ☐ Color Mixing		Curre	ent Sense	☐ DAL	I	☐ DMX		☐ FN Pins				
☐ HB LEDs	B Hysteretic Controller		MOS	FETs	☐ MPF	PT	☐ Modul	ators	☐ PrISM			
☐ Programming ☐	SSDM		Sche	matics	Swit	ching Regulators	☐ Trip		☐ Voltage	Regulator		
							•	•				
Wireless/RF Tags												
☐ 2.4 GHz		□ 8DR		Antenna		Audio		ПА	gileHID		Bridg	ıe
☐ CY3271 ☐ CY3630			☐ CY4636		☐ CY4672		CYFI			CYF		
☐ CYRF6936 ☐ CYRF7936		36] Channel		DDR			SSS		GFS	K	
HID		HUB] IRQ		☐ Interference	Avoidance	☐ Ke	eyboard		Link	Budget
Mouse		□ Node] PMU		☐ PN Code		☐ PF	RoC		☐ PRo	C-CS
☐ PRoC-EMB ☐ PRoC-TT		т [☐ PRoC-USB		☐ PRoC-UI		☐ Po	ower Amplifie	er	☐ Prea	mble	
☐ Pseudo Noise code	Э	□RF		RSSI		Range		□R€	emote		SCD	
SDR		SOP		SPIM		Star-Network	Protocol	☐ St	reaming		☐ Tracl	краd
Wireless		☐ Wireless	USB [] Wireless l	JSB LP	☐ Wireless USE	3 LS	□W	ireless USB	LR	☐ Wire	less USB NL
☐ Wireless Capacitive	e Touch											
Memory Tags												
			_ <u></u> _			Γ_				<u> </u>		
Address Bus		sync		motive		Autostore			HE / BLE	BUSY		
☐ Battery Backup		Burst	∐ Bus (Contention		Clock			DR	☐ Data Bu	S	
☐ Data Integrity	_	oata ention	☐ Data	sheet		☐ Dual Port		☐ Echo Clocks ☐ FIFO		FIFO		
☐ FPGA	F	lags	☐ Flow	hrough		☐ Fullflex			RAM	HOLD	_	
☐ HD-FIFO	□н	ISB	☐ I2C			1 1 1 INI 1 —		☐ Im	npedance	☐ Interface		



☐ Interleaving	☐ JTAG [☐ Junction Temperature	☐ Low Power	☐ MSL [Migration Path
MoBL	☐ Models [□ NoBL	ODT	Obsolete [PCB
☐ PLL / DLL	☐ Packaging [Parallel	☐ Parity	☐ Part Decoder [Part Difference
☐ Password Protection	Configuration	Pipeline	☐ Power Consumption	n Power On State	Processor
☐ QDR	Qualification Reports	☐ Quality	RECALL	☐ RTC [Race Condition
Read	☐ SER [SPCM	SPI	☐ SRAM [Serial
☐ Signal Integrity	☐ Sync [Technology	☐ Termination	☐ Timing [☐ Vcap
□Vddq	☐ Voltage Levels	☐ Vref	☐ Width / Depth Expansion	☐ Write [nvSRAM
uPower					
Interface Tags					
☐ 10B/8B Decoder	3 Level Inputs	ALDEC	☐ ATM	Altera	BIST
BSDL	Biasing	CDR	☐ CML	☐ CPLD	☐ CY3900i
☐ CY3950i	CYUSBISRPC	☐ Cable	☐ Cable Driver	☐ Channel Bonding	☐ Clock Multiplier
☐ Clocking Modes	☐ Coaxial Cable	☐ Copper Cable	☐ Coupling	☐ Crystal	☐ Current
□ DVB	☐ Data Character	r ☐ Data rate	☐ Delta39K	☐ Deserialize	☐ Deserializer
☐ Dual Channel	☐ EPLD	☐ EPROM	☐ ESCON	☐ Elasticity Buffer	☐ Equalizer
☐ Error	☐ Evaluation Boa	rd FPGA	☐ Fiber Optics	☐ Flash370i	Framer
☐ Framing Character	☐ Framing Mode	☐ Gigabit Ethernet	Hex	☐ High Speed Serial Lin	ks Hotlink
☐ HotlinkI	☐ HotlinkII	□IP	☐ Isr	☐ Jtag	☐ LFI
LVTTL	Logic Level	☐ Loop Back	☐ Macrocell	☐ Max340	☐ Model
☐ Non-Volatile	☐ OC-1	☐ OC-2	☐ OC-3	☐ Operating System	☐ PAL
☐ PECL	☐ PLD	☐ PLL	☐ Parallel Input	☐ Parallel Output	☐ Parity
☐ Phase Align Buffer	☐ PoF	☐ Point To Multi Point	☐ Point To Point	☐ Power Supply	☐ Programming
Quad Channel	☐ Quantum38K	Receiver	☐ Recovered Clock	☐ Redundant Outputs	☐ Reference Clock
Report File	Reprogrammat	ole SMA	SMPTE	☐ SMPTE-259M	☐ SMPTE-292M
SONET	SPICE	SPLD	STAPL	SVF	☐ Serial Input
☐ Serial Output	Serializer	Simulator	Size	☐ Special Character	☐ Specification
TTL	☐ Temperature	☐ Third Party Tool	Transceiver	Transmitter	USBISRPC Cable

9



☐ Ultra37K	☐ User Guide	□VHDL	Verilog	□ Voltage	□Warp
☐ Word Sync Sequence			verneg	voltage	
*** PSoC 1 Tags					
ADC	ADCINC	☐ Analog	☐ Analog Bus	☐ API	☐ Assembly Language
☐ Boot.asm	☐ Bootloader	☐ BSDL Files	☐ Build Errors	☐ Calibration	Capsense
Clock	Clock Synchronization	Cloning	☐ Column Clock	☐ Communication	☐ Comparator
Compiler	Counter	☐ CPU Speed	☐ Crystal	☐ CT Block	☐ DAC
☐ Debugging	☐ Decimator	☐ Delta Sigma ADC	Development k	Kit Digital	Dynamic Reconfiguration
☐ ECO	☐ EEPROM	☐ Errata	Filter	☐ Flash	☐ Flash Security
☐ Global Resources	☐ GPIO	☐ Hex File	☐ I2C	☐ I2C-USB Bridge	☐ ICE Cube
Installation	☐ Internet Explorer	☐ Interrupt	☐ ISR	☐ ISSP	☐ Large Memory Model
LCD	License	☐ MAC	☐ MiniProg1	☐ MiniProg3	☐ Mux
☐ Mux Bus	OCD	☐ Offset	Pod	☐ Port and Pins	☐ Power Management
☐ Production Programmer	☐ PWM	RAM	RTC	SAR	☐ SC Block
SMP	☐ SPI	System Level Design	☐ Timer	☐ UART	USB
☐ USBUART	☐ Watchdog	☐ Amplifier UM	☐ Analog Referen	ce Analog UM	☐ Build Tools
☐ Communication UM	☐ CRC UM	CYFI	☐ Device Programming	☐ Digital UM	☐ DTMF
☐ Fan Controller UM	☐ Firmware UM	☐ FMEA	☐ Port Expander	☐ PSoC Power System Architecture	□ Voltage Sequencer UM

PSoC 3/4/5 Tags					
Component Tags				-	1
	<u> </u>		☐ Bootloader /	<u> </u>	
☐ Analog Hardware Mux	☐ Analog Mux	☐ Boost Converter	Bootloadable	☐ CAN	☐ CapSense_CSD



	1				
☐ Character LCD	☐ Clock	☐ Comparator	Control / Status Register	☐ Counter	☐ CRC
☐ DAC	☐ Debouncer	☐ Delta Sigma ADC	☐ DFB	☐ DFB Assembler	☐ Die Temperature
☐ Digital Comparator	☐ Digital Multiplexer	☐ DMA	☐ EEPROM	emFile SPI Mode	☐ EMIF
☐ Ezl2C Slave	☐ Fan Controller	☐ Filter	☐ Frequency Divider	☐ Glitch Filter	Global Signal Reference
☐ Graphic LCD	☐ I2C /I 2S	□iAP	☐ Interrupt	LIN	☐ Logic Gates
Lookup Table	☐ Manual Routing	☐ MDIO	Mixer	☐ Opamp	□PGA
Ports and Pins	☐ Power Monitor	☐ PRS	PWM	☐ Quadrature Decoder	☐ Resistive Touch
RTC	☐ RTD Calculator	Sample / Track and Hold	☐ SAR ADC	☐ SAR Sequencer	☐ Segment LCD
☐ SGPIO	☐ Shift Register	☐ Sleep Timer	SM / PMBus	SPDIF	SPI
Sync	☐ Thermistor Calculator	☐ Thermocouple Calculator	□TIA	☐ Timer	☐ TMP05 Interface
☐ TrimMargin	□UART	□ UDBClkEn	USBFS	USBMIDI	USBUART (CDC Interface)
☐ Voltage Fault Detector	☐ Voltage Sequencer	☐ Vref	☐ WaveDAC		
General Tags					
☐ Analog Bus	☐ Analog Global Bus	☐ Analog Mux Bus	☐ API	☐ Application Specific	☐ Assembly Language
☐ Bootloader Host	☐ Boundary Scan / BSDL	☐ Bridge Control Panel	☐ Build Settings	Clock	☐ Compiler - GCC
☐ Compiler - KEIL	☐ Compiler - MDK	☐ Compiler - RVDS	☐ Cortex-M0	☐ Cortex-M3	☐ Creator Registration
Custom Component Interconnect	☐ Datapath Configuration Tool	Debugging	☐ DMA Wizard	□ DVK	□ ECO
☐ Errata	☐ Error Message	☐ Flash	☐ Hex File	☐ Installation	☐ ISSP / HSSP
☐ KEIL Registration	Linux Platform	☐ Low Power Modes	☐ LVD / HVD	☐ MFi	☐ MiniProg3
Optimization	☐ Programmer COM	☐ PSoC Creator	⊠ PSoC Programmer	Reset	RTOS
Schematic	Silicon	Software Download	□STA	☐ Supply Voltage	System Reference Guide
☐ Verilog	☐ Watchdog	☐ Windows Platform			
Kit Tags					
☐ CAN / LIN EBK	☐ CapSense Expansion EBK	CY8CKIT-001 Kit	CY8CKIT-030 / 050 Kit	☐ CY8CKIT-042 Kit	☐ Digital Audio EBK
☐ First Touch Kit	LCD Segment Drive EBK	☐ MFI EBK	☐ Power Supervisor EBK	PSoC 3/4/5 Processor Module	☐ Thermal Management EBK



**

Touch Sensing Tags

☐ ADC	☐ Air gap	Backlighting	Blee	eder Resistor	Bootloader	ПС	MOD
☐ CSA	□CSD	☐ CSD Parameters	IIII		☐ CSDADC	С	SDAUTO
☐ CY3203A	☐ CY3213A	CY3214	☐ CY3	3218	☐ CY3280-20x34		Y3280-20xx6
☐ CY3280-21x34	☐ CY8C20x34	CY8C20xx6	EX		CY8C21xxx-CapSense Express	xxx-CapSense	
CY8CMBR2044	☐ CapSense Express	☐ Circuit Housing	☐ Con	ductive Objects	☐ Configuration	□ D	iplexing
Dynamic Reconfiguration	☐ EEPROM	□ ЕМІ	□ ESD [☐ Errors	☐ FI	R4
Filters	☐ Finger Threshold	☐ Flex PCB	PCB 12C		☐ I2C-USB Bridge		OAC
☐ IMO and Prescaler	□ ІТО	Layout Guidelines			□ Noise	o	verlay
☐ PSoC3 CapSense	☐ Parasitic Capacitance	☐ Pathfinder ☐ Power Consumption		☐ Proximity	SI	NR	
SPI	☐ Scanning Techniques	☐ Schematic ☐ Sensors		Shield	SI	liders	
☐ SmartSense	☐ Tuning	☐ UART ☐ Water [☐ Water Proofing			
USB Controllers Tag	S						
□ 8051	☐ AN2131	☐ AT2LP		ATA / ATAPI	ATA Commands		Asynchronous
☐ Auto Mode	Bandwidth	☐ Blaster		Bulk Transfer	☐ Bus Power		☐ C#
☐ C++	☐ CAT5	☐ CF Card		☐ CY3216	☐ CY3649		☐ CY3654
☐ CY3655	☐ CY3660	☐ CY3662		☐ CY3664	☐ CY3674		☐ CY3681
☐ CY3684	☐ CY3685	☐ CY3686		☐ CY4605	☐ CY4606		☐ CY4611B
☐ CY4615	CYUSB	☐ Clock		☐ Compliance	☐ Control Center		☐ Control Transfer
☐ Crystal	☐ CyConsole	☐ DLL		☐ Debug	Descriptors		☐ Driver
☐ EEPROM	☐ EZ-HOST	☐ EZ-OTG		☐ EZ-USB	☐ Emulation		☐ EnCoreII
☐ EnCoreIII	☐ EnCoreV	☐ Encore		☐ Endpoint	☐ Enumeration		☐ Errata
FIFO	□FX	☐ FX1		☐ FX2	☐ FX2LP		Firmware
☐ Firmware Debug	☐ Flags	Framework		☐ Full Speed	GPIF		HDD

☐ Hi-Lo Programmer

☐ High Speed

☐ HX2LP

Document No. 001-96152 Rev. **

☐ HX2

HID

☐ Host Application



Hub	☐ I2C	☐ ICE	☐ IN Transfer	☐ Interrupt Transfer	☐ Interrupts
☐ Isochronous Transfer	☐ Keil	☐ Keyboard	☐ Layout	Library	Loader
☐ Low Speed	☐ M8A		☐ Manual Mode	☐ Mass Storage	☐ Memory
Mouse	☐ NX2LP	☐ NX2LP-Flex	☐ Nand Flash	☐ Nand Manufacturing Utility	ОТР
OUT Transfer	☐ Port IO	Register	Renumeration	Report	Reset
SFR	SIE	☐ SL811HS	SPI	☐ SX2	Schematic
☐ Schematic Review	Screamer	☐ Script	☐ Self Power	☐ Slave FIFO	☐ Streaming
SuiteUSB	Synchronous	☐ TX2	☐ TX2UL	☐ Tetra Hub	☐ Throughput
Timer	□UART	☐ UDMA	USBFS	USBUART	USBSerial
☐ Vendor Command	☐ Video Class	WHQL	□WLK	☐ cyapi	uVision
SuperSpeed					
☐ FX3	ADMux	☐ ARM926EJ -S	☐ Bootloader	☐ DMA	☐ Eclipse
☐ FX3 GPIO	☐ FX3 Power Management	☐ FX3 Power supply	☐ FX3 SDK	☐ GPIF II	☐ HS-OTG
☐JTAG	☐ LPP	☐ MSC	☐ Oscillator	RTOS	☐ SD Card
Slavefifo	☐ USB 3.0	USB Compliance Test	USB Host	□UVC	
☐ FX3S	☐ eMMC	SDIO	☐ S-Ports	☐ Bay	☐ Benicia
☐ HX3	☐ ASSP	☐ Battery charging	Bootloader	Cortex-M0	☐ EEPROM
☐ GPIOs	☐ HX3 Power Management	☐ HX3 Power supply	☐ I2C	☐ In-system programming	☐ Oscillator
USB 3.0 hub	☐ USB Shared Link™				



Knowledge Base Article Type: [Select the category by clicking the checkbox associated]

KB Type-1	KB Type-2
71	ByteCraft
	☐ Imagecraft
Compiler	Keil
	HiTech
	☐ Training/Things you should know
	Component Architecture
	☐ Component/Project management
Composit Development	☐ Datapath
Component Development	☐ Analog components
	☐ Digital components
	☐ Component software/tools
	Component Testing
□ Development Kits	☐ FirstTouch Kit
☐ Development Tools	
Device Drivers	☐ Pullability
☐ Device Drivers	☐ Mass Storage
□ Device Programming	☐ PSoC Programmer
☐ Documentation	
Firmware	
General	
	☐ Digital
Hardware	Specifications
	Analog
☐ Known Problems and Solutions	
	8051
Microcontrollers	☐ M8
	☐ M8C
Modules	



☐ Platforms	☐ MacOS X
	Windows
☐ Protocols	HID
	☐ I2C
Quality	
☐ Reference Designs	
Software	☐ PSoC Designer
	☐ PSoC Creator
User Modules	☐ Analog
	☐ Digital



Document History

Document Title: Updating CY8CKIT-042-BLE KitProg and CySmart USB Dongle Firmware – KBA96152

Document Number: 001-96152

Rev.	ECN No.	Orig. of Change	Description of Change
**	4657504	PMAD	New KB Article

Distribution: WEB Posting: None