






Select this and click next




Select this and click next




Select 2nd radio button




Choose any icon




Select Have Disk



- Browse the following path:
- C:\Program Files\Cypress\Programmer\3.12\drivers\ftk3



- Choose ftk3.inf file



Select Ok

Hardware Update Wizard

Please wait while the wizard installs the software...



FTK3 (3.4.1.20)



PSocUSB.sys

To C:\WINDOWS\system32\drivers\cypress\ftk3



< Back

Next >

Cancel

Hardware Update Wizard



Completing the Hardware Update Wizard

The wizard has finished installing the software for:



FTK3 (3.4.1.20)

The hardware you installed will not work until you restart your computer.

Click Finish to close the wizard.

< Back

Finish

Cancel