



Cypress SPI NOR Flash Low-Level Driver User Guide

Doc. No. 002-00997 Rev. *E

Cypress Semiconductor
198 Champion Court
San Jose, CA 95134-1709
www.cypress.com

Copyrights

© Cypress Semiconductor Corporation, 2010-2018. This document is the property of Cypress Semiconductor Corporation and its subsidiaries, including Spansion LLC ("Cypress"). This document, including any software or firmware included or referenced in this document ("Software"), is owned by Cypress under the intellectual property laws and treaties of the United States and other countries worldwide. Cypress reserves all rights under such laws and treaties and does not, except as specifically stated in this paragraph, grant any license under its patents, copyrights, trademarks, or other intellectual property rights. If the Software is not accompanied by a license agreement and you do not otherwise have a written agreement with Cypress governing the use of the Software, then Cypress hereby grants you a personal, non-exclusive, nontransferable license (without the right to sublicense) (1) under its copyright rights in the Software (a) for Software provided in source code form, to modify and reproduce the Software solely for use with Cypress hardware products, only internally within your organization, and (b) to distribute the Software in binary code form externally to end users (either directly or indirectly through resellers and distributors), solely for use on Cypress hardware product units, and (2) under those claims of Cypress's patents that are infringed by the Software (as provided by Cypress, unmodified) to make, use, distribute, and import the Software solely for use with Cypress hardware products. Any other use, reproduction, modification, translation, or compilation of the Software is prohibited.

TO THE EXTENT PERMITTED BY APPLICABLE LAW, CYPRESS MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS DOCUMENT OR ANY SOFTWARE OR ACCOMPANYING HARDWARE, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. No computing device can be absolutely secure. Therefore, despite security measures implemented in Cypress hardware or software products, Cypress does not assume any liability arising out of any security breach, such as unauthorized access to or use of a Cypress product. In addition, the products described in these materials may contain design defects or errors known as errata which may cause the product to deviate from published specifications. To the extent permitted by applicable law, Cypress reserves the right to make changes to this document without further notice. Cypress does not assume any liability arising out of the application or use of any product or circuit described in this document. Any information provided in this document, including any sample design information or programming code, is provided only for reference purposes. It is the responsibility of the user of this document to properly design, program, and test the functionality and safety of any application made of this information and any resulting product. Cypress products are not designed, intended, or authorized for use as critical components in systems designed or intended for the operation of weapons, weapons systems, nuclear installations, life-support devices or systems, other medical devices or systems (including resuscitation equipment and surgical implants), pollution control or hazardous substances management, or other uses where the failure of the device or system could cause personal injury, death, or property damage ("Unintended Uses"). A critical component is any component of a device or system whose failure to perform can be reasonably expected to cause the failure of the device or system, or to affect its safety or effectiveness. Cypress is not liable, in whole or in part, and you shall and hereby do release Cypress from any claim, damage, or other liability arising from or related to all Unintended Uses of Cypress products. You shall indemnify and hold Cypress harmless from and against all claims, costs, damages, and other liabilities, including claims for personal injury or death, arising from or related to any Unintended Uses of Cypress products.

Cypress, the Cypress logo, Spansion, the Spansion logo, and combinations thereof, WICED, PSoC, CapSense, EZ-USB, F-RAM, and Traveo are trademarks or registered trademarks of Cypress in the United States and other countries. For a more complete list of Cypress trademarks, visit cypress.com. Other names and brands may be claimed as property of their respective owners.

Contents



Contents	3
1. Overview	4
1.1 Function Categories	4
1.2 Parameter Description	4
1.3 Data Types	5
1.4 Functions Returned Value Description	6
1.5 Hardware Abstraction Layer (HAL)	6
2. Functions List.....	7
2.1 Operation Functions	7
2.2 Command Functions	8
2.3 Utility Functions	12
2.4 Files	12
2.5 Porting Considerations	12
2.6 Typedefs	12
3. Appendix – API Details	13
3.1 Operation Functions	13
3.2 Command Functions	29
3.3 Utility Functions	67
3.4 HAL Functions	69
Revision History	71

1. Overview



This document describes the functions and features contained in the SPI NOR Flash Low-Level Driver (SLLD). The SLLD contains both higher-level “operation” functions and low-level “command” functions. The operation functions implement programming operations, erase operations, and protect operations. Additionally, the “command functions” allow the programmer to easily add new functionality by invoking the lower-level command functions in the desired sequence. Refer to [Section 2.5, Porting Considerations on page 12](#) for more details regarding the SLLD system integration.

1.1 Function Categories

The SLLD functions fall into three categories:

- Operation Functions:

These functions implement embedded operations by invoking the “command” functions, and then polling for embedded operation completion.

The operation function naming convention is: `slld_xxxxOp`

For example, `slld_PPOp`

This function implements Page Programming operation

- Command Functions:

These functions send flash command sequences to the device.

The command function naming convention is: `slld_xxxxCmd`

For example, `slld_ReadCmd`

This function writes a Read Command to Flash Device and read data.

- Utility Functions:

Several utility functions are available to a calling application as well. These functions do not act directly on the flash device but encapsulate common tasks.

The utility function names do not have a `Cmd` or `Op` suffix.

For example, `slld_StatusGet`

This function determines the flash device status and returns the information to the caller (for example, device is busy or device is not busy).

1.2 Parameter Description

The following is a list of parameters used in the SLLD.

Parameter	Description
<code>device_num</code>	device number: this parameter will be used on device with multiple chip select.
<code>sys_addr</code>	device address given by system: must be 32 bits
<code>source</code>	a single byte to write to flash
<code>target</code>	variable in which to store read data

Parameter	Description
data_buf	variable containing data to program
len_in_bytes	number of bytes on which to operate
dev_status_ptr	variable to store device status
dev_softwareprotect_status_ptr	variable to store device software protect status
status_val	variable to store status register value
config_val	variable to store configuration register value
asp_val	variable to store ASP register value
bnk_val	variable to store bank addressing register value
abt_val	variable to store Auto Boot register value
mode	variable to the mode bits value

1.3 Data Types

For portability, `typedefs` are used for basic data types.

```
typedef unsigned char BYTE; /* 8 Bits wide */
typedef unsigned short WORD; /* 16 Bits wide */
typedef unsigned long DWORD; /* 32 Bits wide */
typedef BYTE FLASHDATA; /* 8 Bits wide */
```

These definitions may require modification on the target system.

The following additional `typedefs` are used in the SLLD:

ADDRESS	Used for system-level addressing. Must be implemented as a 32-bit unsigned integer.
PARAM	Used for function options.
BYTECOUNT	Indicates number of bytes on which to operate. Typically implemented as a 32-bit unsigned integer.
DEVSTATUS	an <code>enum</code> listing possible device statuses <code>dev_status_unknown,</code> <code>dev_not_busy,</code> <code>dev_program_error,</code> <code>dev_erase_error,</code> <code>dev_suspend,</code> <code>dev_busy.</code>
DEV_SOFTWARE_PROTECT_STATUS	an <code>enum</code> listing possible device software protect statuses <code>FLASH_SOFTWARE_UNPROTECTED</code> <code>FLASH_SOFTWARE_PROTECTED</code>
SLLD_STATUS	an <code>enum</code> listing function return values <code>SLLD_OK,</code> <code>SLLD_E_DEVICE_SOFTWARE_PROTECTED,</code> <code>SLLD_E_HAL_ERROR,</code> <code>SLLD_ERROR.</code>

1.4

Functions Returned Value Description

The following returned values are listed in an `enum SLLD_STATUS`.

`SLLD_OK` Function finishes successfully.

Note: For some operation functions (for example, `slld_PPOp`, `slld_SEOp`) if the target area is protected, the function returns `SLLD_OK` but the device does not execute the operation. In this case, you will have to check the `dev_status_ptr` returned value.

`SLLD_E_DEVICE_SOFTWARE_PROTECTED`

Command is not accepted because the target device is in the software protect mode.

`SLLD_E_HAL_ERROR` Error occurs during HAL function.

`SLLD_ERROR` Error occurs during operation function.

1.5

Hardware Abstraction Layer (HAL)

The Hardware Abstraction Layer is used to adapt the SLLD to the target system.

The SLLD HAL consists of two functions:

`FLASH_READ(...)` Basic read function – (one CS# cycle).

`FLASH_WRITE(...)` Basic write function – (one CS# cycle).

These functions return `SLLD_OK` on success and `SLLD_E_HAL_ERROR` on failure.

They take the following parameters:

```
BYTE      device_num, /* device number */  
BYTE      command, /* command to write to the SPI flash */  
ADDRESS   sys_addr, /* system address to be used */  
BYTE      *data_buffer, /* Pointer to the data buffer containing data to be written (respectively to be read) */  
int       Number_Of_Bytes /* number of bytes to be written */
```

The basic source code for the HAL functions is provided. However, this code is not complete and changes will be required in the HAL functions to adapt them to the target system and optimize them for performance. The provided source code contains comments that will guide you through your customization process.

2. Functions List



For the details, refer to [Appendix – API Details chapter on page 13](#).

2.1 Operation Functions

Command	Description
<code>slld_WriteOp</code>	Performs a Single / Quad Page Programming Operation
<code>slld_ReadOp</code>	Performs a Single / Fast / Dual / Quad Read Operation
<code>slld_PPOp</code>	Performs a Page Programming Operation
<code>slld_PP_4BOP</code>	Performs a Page Programming Operation using 4-bytes addressing scheme
<code>slld_QPPOp</code>	Performs a Quad input Page Programming Operation
<code>slld_QPP_4BOP</code>	Performs a Quad input Page Programming Operation using 4-bytes addressing scheme
<code>slld_BufferedProgramOp</code>	Performs a Programming Operation. Unlike <code>slld_PPOp</code> , this function enables program operation over page boundary
<code>slld_BufferedProgram_4BOP</code>	Performs a Programming Operation using 4-bytes addressing scheme. Unlike <code>slld_PP_4BOP</code> , this function enables program operation over page boundary
<code>slld_OTPPOp</code>	Performs a OTP Programming Operation
<code>slld_SEOp</code>	Performs a Sector Erase Operation
<code>slld_SE_4BOP</code>	Performs a Sector Erase Operation using 4-bytes addressing scheme
<code>slld_P4EOp</code>	Performs a Parameter sector Erase Operation. This function erases one of the 4 KB sectors
<code>slld_P8EOp</code>	Performs a Parameter sector Erase Operation. This function erases two of the 4 KB sectors
<code>slld_P8E_4BOP</code>	Performs a Parameter sector Erase Operation using 4-bytes addressing scheme. This function erases two of the 4 KB sectors
<code>slld_BEOp</code>	Performs a Bulk Erase Operation
<code>slld_WRSROp</code>	Performs a Write Status Register Operation
<code>slld_WRROp</code>	Writes a Write Registers Command Sequence to Flash Device
<code>slld_WASPOp</code>	Writes a Write ASP Command Sequence to Flash Device
<code>slld_WBNKOp</code>	Writes a Write bank addressing Command Sequence to Flash Device
<code>slld_WABTOp</code>	Writes a Write Auto Boot Command Sequence to Flash Device
<code>slld_WPWDOP</code>	Writes a Write password Command Sequence to Flash Device
<code>slld_BlockProtectOp</code>	Performs a Block Protect Operation
<code>slld_PPBP_GOp</code>	Performs a PPB programming Operation
<code>slld_DYB_GOp</code>	Performs a DYB programming Operation
<code>slld_BE32KBOp</code>	Performs a 32KB Block Erase Operation, used for FLK devices
<code>slld_WRAR_Op</code>	Performs a Write Any Register Operation
<code>slld_PPBP_Op</code>	Performs a PPB programming Operation for FSS devices
<code>slld_DYBWR_Op</code>	Performs a DYB Write Operation for FSS devices

Command	Description
<code>slld_IRPPOp</code>	Performs a Write IRP Register Operation
<code>slld_SECRPOp</code>	Performs a Secure Region Programming Operation
<code>slld_SECREOp</code>	Performs a Secure Region Erase Operation
<code>slld_HBEOp</code>	Performs a Half Block Erase Operation
<code>slld_CEOp</code>	Performs a Chip Erase Operation
<code>slld_CE1Op</code>	Performs an alternative Chip Erase Operation
<code>slld_IBLOp</code>	Performs a IBL lock Operation
<code>slld_IBULOp</code>	Performs a IBL unlock Operation
<code>slld_GBLOp</code>	Performs a GBL lock Operation
<code>slld_GBULOp</code>	Performs a GBL unlock Operation
<code>slld_SPRPOp</code>	Performs Set Pointer Region Protection Operation
<code>slld_BlockEraseOp</code>	Performs Block Erase Operation
<code>slld_DataIntgChkOp</code>	Performs a Data Integrity Check Operation
<code>slld_SecEraseCntOp</code>	Performs a Sector Ease Count Operation
<code>slld_ECCCheckOp</code>	Performs a ECC error count check Operation

2.2 Command Functions

All Command Functions except `slld_Read_IDCmd`, `slld_SPCmd`, and `slld_RESCmd` check the software protect status of the target device (this information is stored in RAM) before issuing command sequences.

Command	Description
<code>slld_ReadCmd</code>	Writes a Read Command to Flash Device and reads data
<code>slld_Read_4BCmd</code>	Writes a Read Command to Flash Device and reads data using 4-bytes addressing scheme
<code>slld_Fast_ReadCmd</code>	Writes a Flash Read Command Sequence to Flash Device and read data
<code>slld_Fast_Read_4BCmd</code>	Writes a Flash Read Command Sequence to Flash Device and reads data using 4-bytes addressing scheme
<code>slld_DualIOReadCmd</code>	Writes a Dual I/O Read Command to Flash Device and reads data
<code>slld_DualIORead_4BCmd</code>	Writes a Dual I/O Read Command to Flash Device and reads data using 4-bytes addressing scheme
<code>slld_DualIOHPReadCmd</code>	Writes a Dual I/O High Performance Read Command to Flash Device and reads data
<code>slld_DualIOHPRead_4BCmd</code>	Writes a Dual I/O High Performance Read Command to Flash Device and read data using 4-bytes addressing scheme
<code>slld_QuadIOReadCmd</code>	Writes a Quad I/O Read Command to Flash Device and reads data
<code>slld_QuadIORead_4BCmd</code>	Writes a Quad I/O Read Command to Flash Device and reads data using 4-bytes addressing scheme
<code>slld_QuadIOHPReadCmd</code>	Writes a Quad I/O High Performance Read Command to Flash Device and reads data
<code>slld_QuadIOHPRead_4BCmd</code>	Writes a Quad I/O High Performance Read Command to Flash Device and reads data using 4-bytes addressing scheme
<code>slld_Read_IDCmd</code>	Writes a Read ID Command Sequence to Flash Device and reads Device_ID
<code>slld_RDIDCmd</code>	Writes a RDID Command Sequence to Flash Device and reads Device_ID
<code>slld_Read_IdentificationCmd</code>	Writes a Read Electronic ID Command Sequence to Flash Device and reads Device_ID
<code>slld_RDSRCmd</code>	Writes a Read from Status Register Command Sequence to Flash Device and reads status register
<code>slld_SRSTCmd</code>	Writes the software reset command to the flash device
<code>slld_RASPCmd</code>	Writes a Read from ASP Register Command Sequence to Flash Device and reads ASP register
<code>slld_RBNKCmd</code>	Writes a Read from Bank Addressing Register Command Sequence to Flash Device and reads the bank addressing register

Command	Description
<code>sld_RABTCmd</code>	Writes a Read from Auto Boot Register Command Sequence to Flash Device and reads Auto Boot register
<code>sld_RECCCmd</code>	Writes a Read from ECC Register Command Sequence to Flash Device and reads ECC register
<code>sld_RPWDCmd</code>	Writes a Read from password Command Sequence to Flash Device and reads the password
<code>sld_RCRCmd</code>	Writes a Read Configuration Register Command Sequence to Flash Device and reads configuration register
<code>sld_WRENCmd</code>	Writes a Write Enable Command Sequence to Flash Device
<code>sld_WRDICmd</code>	Writes a Write Disable Command Sequence to Flash Device
<code>sld_WRSRCmd</code>	Writes a Write Status Register Command Sequence to Flash Device
<code>sld_WRRCmd</code>	Writes a Write Registers Command Sequence to Flash Device
<code>sld_WASPCmd</code>	Writes a Write ASP register Command Sequence to Flash Device
<code>sld_WBNKCmd</code>	Writes a Write bank addressing Command Sequence to Flash Device
<code>sld_WABTCmd</code>	Writes a Write Auto Boot Register Command Sequence to Flash Device
<code>sld_WPWDCmd</code>	Writes a write password Command Sequence to Flash Device
<code>sld_PP Cmd</code>	Writes a Page Program Command Sequence to Flash Device
<code>sld_PP_4BCmd</code>	Writes a Page Program Command Sequence to Flash Device using 4-bytes addressing scheme
<code>sld_QPPCmd</code>	Writes a Quad input Page Program Command Sequence to Flash Device
<code>sld_QPP_4BCmd</code>	Writes a Quad input Page Program Command Sequence to Flash Device using 4-bytes addressing scheme
<code>sld_SECmd</code>	Writes a Sector Erase Command Sequence to Flash Device
<code>sld_SE_4BCmd</code>	Writes a Sector Erase Command Sequence to Flash Device using 4-bytes addressing scheme
<code>sld_ERS_SSPCmd</code>	Writes a Sector Erase Suspend command to Flash Device
<code>sld_ERS_RESCmd</code>	Writes a Sector Erase Resume command to Flash Device
<code>sld_RCVRCmd</code>	Writes a Initiate Recovery mode command to Flash Device
<code>sld_RCSPCmd</code>	Writes a Recovery Suspend command to Flash Device
<code>sld_RCRSCmd</code>	Writes a Recovery Resume command to Flash Device
<code>sld_P4ECmd</code>	Writes a 4KB Parameter Sector Erase Command Sequence to Flash Device
<code>sld_P8ECmd</code>	Writes an 8KB Parameter Sector Erase Command Sequence to Flash Device
<code>sld_P8E_4BCmd</code>	Writes an 8 KB Parameter Sector Erase Command Sequence to Flash Device using 4-bytes addressing scheme
<code>sld_BECmd</code>	Writes a Bulk Erase Command Sequence to Flash Device
<code>sld_OTPPCmd</code>	Writes an OTP Program Command Sequence to Flash Device
<code>sld_OTPRCmd</code>	Writes an OTP Read Command Sequence to Flash Device and reads OTP
<code>sld_SPCmd</code>	Writes a Software Protect Command Sequence to Flash Device
<code>sld_RESCmd</code>	Writes a RES Command Sequence to Flash Device
<code>sld_ClearStatusRegisterCmd</code>	Writes a Clear Status Register Command Sequence to Flash Device
<code>sld_PPB_PGCmd</code>	Writes a PPB program Command Sequence to Flash Device
<code>sld_DYB_PGCmd</code>	Writes a DYB program Command Sequence to Flash Device
<code>sld_DPCmd</code>	Writes a Deep Power down Command Sequence to Flash Device
<code>sld_BE32KBCmd</code>	Writes a Block Erase 32KB Command Sequence to Flash Device
<code>sld_WRARCmd</code>	Writes a Write Any Register Command Sequence to Flash Device
<code>sld_PPBP_Cmd</code>	Writes a PPB Program Command Sequence to Flash Device
<code>sld_DYBWR_Cmd</code>	Writes a DYB write Command Sequence to Flash Device

Command	Description
<code>sld_RReadSFDPCmd</code>	Writes a Read SFDP Command Sequence to Flash Device, and read SFDP values
<code>sld_RDCR2Cmd</code>	Writes a Read Configuration register 2 Command Sequence to Flash Device, and read register value
<code>sld_RDCR3Cmd</code>	Writes a Read Configuration register 3 Command Sequence to Flash Device, and read register value
<code>sld_IRPRDCmd</code>	Writes a Read IRP register Command Sequence to Flash Device, and read register value
<code>sld_IRPPCmd</code>	Writes a Write IRP register Command Sequence to Flash Device
<code>sld_QPIENCmd</code>	Writes a Enter QPI Command Sequence to Flash Device
<code>sld_QPIEXCmd</code>	Writes a Exit QPI Command Sequence to Flash Device
<code>sld_4BENCmd</code>	Writes a Enter 4 Bytes Address Mode Command Sequence to Flash Device
<code>sld_4BEXCmd</code>	Writes a Exit 4 Bytes Address Mode Command Sequence to Flash Device
<code>sld_DORCmd</code>	Writes a Dual Output Command Sequence to Flash Device and read data
<code>sld_4DORCmd</code>	Writes a 4Byte Dual Output Command Sequence to Flash Device and read data
<code>sld_DIORCmd</code>	Writes a Dual IO Command Sequence to Flash Device and read data
<code>sld_4DIORCmd</code>	Writes a 4B Dual IO Command Sequence to Flash Device and read data
<code>sld_QORCmd</code>	Writes a Quad Output Command Sequence to Flash Device and read data
<code>sld_4QORCmd</code>	Writes a 4B Quad Output Command Sequence to Flash Device and read data
<code>sld_QIORMd</code>	Writes a Quad IO Command Sequence to Flash Device and read data
<code>sld_4QIORMd</code>	Writes a 4B Quad IO Command Sequence to Flash Device and read data
<code>sld_DDRQIORMd</code>	Writes a DDR Quad IO Command Sequence to Flash Device and read data
<code>sld_4DDRQIORMd</code>	Writes a 4B DDR Quad IO Command Sequence to Flash Device and read data
<code>sld_SECRRCmd</code>	Writes a Secure Region read Command Sequence to Flash Device and read secure region data
<code>sld_SECRPCmd</code>	Writes a Secure Region program Command Sequence to Flash Device
<code>sld_SECRECmd</code>	Writes a Secure Region erase Command Sequence to Flash Device
<code>sld_RUIDCmd</code>	Writes a Read UID Command Sequence to Flash Device and read UID value
<code>sld_WRENVCmd</code>	Writes a Write Enable for Volatile Register Command Sequence to Flash Device
<code>sld_HBECmd</code>	Writes a Half Block Erase Command Sequence to Flash Device
<code>sld_4HBECmd</code>	Writes a 4B Half Block Erase Command Sequence to Flash Device
<code>sld_4BECmd</code>	Writes a 4B Block Erase Command Sequence to Flash Device
<code>sld_CECmd</code>	Writes a Chip Erase Command Sequence to Flash Device
<code>sld_CE1Cmd</code>	Writes an alternative Chip Erase Command Sequence to Flash Device
<code>sld_IBLRDCmd</code>	Writes a IBL read Command Sequence to Flash Device and read IBL bit
<code>sld_4IBLRDCmd</code>	Writes a 4B IBL read Command Sequence to Flash Device and read IBL bit
<code>sld_IBLCmd</code>	Writes a IBL lock Command Sequence to Flash Device
<code>sld_4IBLCmd</code>	Writes a 4B IBL lock Command Sequence to Flash Device
<code>sld_IBULCmd</code>	Writes a IBL unlock Command Sequence to Flash Device
<code>sld_4IBULCmd</code>	Writes a 4B IBL unlock Command Sequence to Flash Device
<code>sld_GBLCmd</code>	Writes a Global IBL lock Command Sequence to Flash Device
<code>sld_GBULCmd</code>	Writes a Global IBL unlock Command Sequence to Flash Device
<code>sld_SPRPCmd</code>	Writes a Set Pointer Region Protection Command Sequence to Flash Device
<code>sld_4SPRPCmd</code>	Writes a 4B Set Pointer Region Protection Command Sequence to Flash Device
<code>sld_PRLCmd</code>	Writes a Protection Register lock Command Sequence to Flash Device
<code>sld_PRRDCmd</code>	Writes a Protection Register Read Command Sequence to Flash Device and read data

Command	Description
<code>sld_SBLCmd</code>	Writes a Set Burst Length Command Sequence to Flash Device
<code>sld_MBRCmd</code>	Writes Mode Bit Reset Command Sequence to Flash Device
<code>sld_BlockEraseCmd</code>	Write Block Erase Command Sequence to Flash Device
<code>sld_RDQIDCmd</code>	Writes a RDQID Command Sequence to Flash Device and reads Device_ID in Quad All mode
<code>sld_RDSR2Cmd</code>	Writes a Read from Status Register 2 Command Sequence to Flash Device and reads status register 2
<code>sld_RDARCmd</code>	Writes a Read Any Register Command Sequence to Flash Device and reads register value
<code>sld_DLPRDCmd</code>	Writes a DLPRD Command Sequence to Flash Device and read data
<code>sld_PNVDLRCmd</code>	Writes a Program NV Data Learning Register Command Sequence to Flash Device
<code>sld_WVDLRCmd</code>	Writes a Write Volatile Data Learning Register Command Sequence to Flash Device
<code>sld_EPS_Cmd</code>	Writes a Sector Erase suspend Command Sequence to Flash Device
<code>sld_EPR_Cmd</code>	Writes a Sector Erase resume Command Sequence to Flash Device
<code>sld_4BAM_Cmd</code>	Writes a 4-Byte Address Mode Command Sequence to Flash Device
<code>sld_PASSRDCmd</code>	Writes a Password Read Command Sequence to Flash Device and read password
<code>sld_PASSPCmd</code>	Writes a Password Write Command Sequence to Flash Device
<code>sld_PASSUCmd</code>	Writes a Password Unlock Command Sequence to Flash Device
<code>sld_RSTCmd</code>	Writes a Software Reset Command Sequence to Flash Device
<code>sld_RSTENCmd</code>	Writes a Software Reset Enable Command Sequence to Flash Device
<code>sld_DICCmd</code>	Write a Data Integrity Check read command to Flash Device
<code>sld_SECCmd</code>	Write a Sector Erase Count command to Flash Device
<code>sld_RUIDCmd</code>	Write a Read Identification command to Flash Device and read data
<code>sld_CLECCCmd</code>	Issue a clear ECC register command to Flash Device
<code>sld_MB_4BEXCmd</code>	Issue a exit 4 bytes address mode command to Flash Device
<code>sld_EnduraFlexCfg</code>	Write the EndruFlex Pointer address registers 4 to 0
<code>sld_WriteNV_Cfg</code>	Writes all the NV configuration registers
<code>sld_EnterQPIMode_Cfg</code>	Enter QPI mode through configure volatile register
<code>sld_ExitQPIMode_Cfg</code>	Exit QPI mode through configure volatile register
<code>sld_RICRCCmd</code>	Send Read interface CRC command Sequence to Flash Device and get interface CRC data
<code>sld_SDROPIRCmd</code>	Writes a SDR OPI read Command Sequence to Flash Device and read data
<code>sld_DDROPIRCmd</code>	Writes a DDR OPI read Command Sequence to Flash Device and read data
<code>sld_EnterOPIMode</code>	Enter OPI mode through configure volatile register
<code>sld_ExitOPIMode</code>	Exit OPI mode through configure volatile register

2.3 Utility Functions

slld_Poll

Polls flash device for embedded operation completion

slld_StatusGet

Determines Flash Status

slld_SoftwareProtectStatusGet

Gets the software protect status from the variable in RAM

slld_GetDevNumFromAddr

Get device number from address

2.4 Files

The SLLD source code is provided as five files (three header files and two C source code files).

File	Description
slld.h	header file containing SLLD function prototypes
slld_hal.h	header file containing HAL function prototypes
slld_target_specific.h	header file containing code customization macros
slld.c	C file containing SLLD function definitions
slld_hal_example.c	C example file containing HAL function definitions

Optionally, we provide the `trace.c` / `trace.h` modules that allow you to enable the software traces, which helps during the debug phases.

2.5 Porting Considerations

Cypress' SLLD is written in ANSI C for easy integration with customer applications. To port the SLLD to a given system, the programmer must modify HAL `typedefs` `#defines` and system-specific HAL functions.

The `slld_target_specific.h`, `slld_hal.h` and `slld.h` files contain all defines that must be changed when porting the SLLD to your system. You can also find in the `slld_hal.h` header file the API parameters and the HAL function prototypes.

The `slld_target_specific.h` header file allows you to customize the SLLD code by enabling or disabling some features which you might not be using or in case you are worried about the code footprint. You should enable the correspondent macro to the device you are using in your system (FL-A, FL-D, FL-P...).

The S/W Trace feature should be enabled here by un-commenting the line where the 'TRACE' macro is defined. Nevertheless, and to be able to use the S/W trace, make sure to link `trace.c` in your project. This module is made available upon your request through the Cypress technical support web form.

2.6 Typedefs

The following `typedefs`, located in `slld.h`, may need to be updated for your target system:

```
typedef unsigned char BYTE; /* 8 bits wide */
typedef unsigned short WORD; /* 16 bits wide */
typedef unsigned long DWORD; /* 32 bits wide */
```

If these default assignments are convenient for your target system, no modification is required.

On the other hand, `FLASH_READ()` and `FLASH_WRITE()` functions in `slld_hal_example.c` have to be adapted to reflect your controller specifications and requirements, which is going to drive the SPI chip cycles. You can find some helping comments in the locations where your specific target code has to be inserted.

3. Appendix – API Details



3.1 Operation Functions

Function Name	<code>slld_WriteOp</code>
Purpose	Performs a Single / Quad Page Programming Operation
Parameters	
<code>device_num</code>	device number
<code>sys_addr</code>	device address given by system
<code>data_buf</code>	variable containing data to program
<code>len_in_bytes</code>	number of bytes to program
<code>dev_status_ptr</code>	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	<p>This function programs location to the specified data. If the data size to program is larger than PAGE_SIZE, this function will execute page programming operation.</p> <p>NOTE: If the page boundary is encountered during page programming, additional bytes are wrapped around to the start of the same page.</p> <p>If WriteOp is attempted on the protected area, the function returns SLLD_OK but program operation is not executed.</p>

Function Name	<code>slld_ReadOp</code>
Purpose	Performs a Single / Fast, Dual / Quad Read Operation
Parameters	
<code>device_num</code>	device number
<code>sys_addr</code>	device address given by system
<code>target</code>	variable in which to store read data
<code>len_in_bytes</code>	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Read commands (Single / Fast / Dual / Quad) to SPI Flash and reads data from the array. Data size is specified by <code>len_in_bytes</code> .

Function Name	slld_PPOp
Purpose	Performs a Page Programming Operation
Parameters	
device_num	device number
sys_addr	device address given by system
data_buf	variable containing data to program
len_in_bytes	number of bytes to program
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	<p>This function programs location to the specified data. If the data size to program is larger than PAGE_SIZE this function returns SLLD_ERROR and does not execute operation.</p> <p>Note: If the page boundary is encountered during page programming, additional bytes are wrapped around to the start of the same page.</p> <p>If PPOp is attempted on the protected area, the function returns SLLD_OK but program operation is not executed.</p>

Function Name	slld_PP_4BOp
Purpose	Performs a Page Programming Operation using 4-bytes addressing scheme
Parameters	
device_num	device number
sys_addr	device address given by system
data_buf	variable containing data to program
len_in_bytes	number of bytes to program
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	<p>This function programs location to the specified data. If the data size to program is larger than PAGE_SIZE this function returns SLLD_ERROR and does not execute operation.</p> <p>Note: If the page boundary is encountered during page programming, additional bytes are wrapped around to the start of the same page.</p> <p>If PP_4BOp is attempted on the protected area, the function returns SLLD_OK but program operation is not executed.</p>

Function Name	<code>slld_QPPOp</code>
Purpose	Performs a Quad input Page Programming Operation
Parameters	
device_num	device number
sys_addr	device address given by system
data_buf	variable containing data to program
len_in_bytes	number of bytes to program
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	<p>This function programs location to the specified data. If the data size to program is larger than PAGE_SIZE this function returns SLLD_ERROR and does not execute operation.</p> <p>Note: If the page boundary is encountered during page programming, additional bytes are wrapped around to the start of the same page.</p> <p>If QPPOp is attempted on the protected area, the function returns SLLD_OK but program operation is not executed.</p>

Function Name	<code>slld_QPP_4BOp</code>
Purpose	Performs a Quad input Page Programming Operation using 4-bytes addressing scheme
Parameters	
device_num	device number
sys_addr	device address given by system
data_buf	variable containing data to program
len_in_bytes	number of bytes to program
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	<p>This function programs location to the specified data using 4-bytes addressing scheme. If the data size to program is larger than PAGE_SIZE this function returns SLLD_ERROR and does not execute operation.</p> <p>Note: If the page boundary is encountered during page programming, additional bytes are wrapped around to the start of the same page.</p> <p>If QPP_4BOp is attempted on the protected area, the function returns SLLD_OK but program operation is not executed.</p>

Function Name	slld_BufferedProgramOp
Purpose	Performs a Programming Operation
Parameters	
device_num	device number
sys_addr	device address given by system
data_buf	variable containing data to program
len_in_bytes	number of bytes to program
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function programs location to the specified data. There is no limitation on data size to program. If the page boundary is encountered during BufferedProgramOp, additional bytes are written to the start of the next page. If BufferedProgramOp is attempted on the protected area, the function returns SLLD_OK but program operation on the protected area are not executed.

Function Name	slld_BufferedProgram_4BOp
Purpose	Performs a Programming Operation using 4-bytes addressing scheme
Parameters	
device_num	device number
sys_addr	device address given by system
data_buf	variable containing data to program
len_in_bytes	number of bytes to program
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function programs location to the specified data using 4-byte addressing scheme. There is no limitation on data size to program. If the page boundary is encountered during BufferedProgram_4BOp, additional bytes are written to the start of the next page. If BufferedProgram_4BOp is attempted on the protected area, the function returns SLLD_OK but program operation on the protected area are not executed.

Function Name	slld_OTPPOp
Purpose	Performs a OTP Programming Operation
Parameters	
device_num	device number
sys_addr	device address given by system
data_buf	variable containing data to program
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function programs specified data in the OTP region, which is in a different address space from the main array data.

Function Name	<code>slld_SEOp</code>
Purpose	Performs a Sector Erase Operation
Parameters	
device_num	device number
sys_addr	device address given by system
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function erases the data in the specified Sector. Function issues all required commands and polls for completion. If SEOp is attempted on the protected area, the function returns SLLD_OK but erase operation is not executed.

Function Name	<code>slld_SE_4BOp</code>
Purpose	Performs a Sector Erase Operation using 4-bytes addressing scheme.
Parameters	
device_num	device number
sys_addr	device address given by system
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function erases the data in the specified Sector. Function issues all required commands and polls for completion. If SE_4BOp is attempted on the protected area, the function returns SLLD_OK but erase operation is not executed.

Function Name	<code>slld_P4EOp</code>
Purpose	Performs a 4 KB Parameter Sector Erase Operation
Parameters	
device_num	device number
sys_addr	device address given by system
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function erases the data in one of the 4 KB Parameter Sector. Function issues all required commands and polls for completion. If P4EOp is attempted on the protected area, the function returns SLLD_OK but erase operation is not executed.

Function Name	slld_P8EOp
Purpose	Performs a 8 KB Parameter Sector Erase Operation
Parameters	
device_num	device number
sys_addr	device address given by system
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function erases the data in two of the 4 KB Parameter Sector. Function issues all required commands and polls for completion. If P8EOp is attempted on the protected area, the function returns SLLD_OK but erase operation is not executed.

Function Name	slld_P8E_4BOp
Purpose	Performs a 8KB Parameter Sector Erase Operation using 4-bytes addressing scheme
Parameters	
device_num	device number
sys_addr	device address given by system
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function erases the data in two of the 4 KB Parameter Sector using 4-bytes addressing scheme. Function issues all required commands and polls for completion. If P8E_4BOp is attempted on the protected area, the function returns SLLD_OK but erase operation is not executed.

Function Name	slld_BEOp
Purpose	Performs a Bulk Erase Operation
Parameters	
device_num	device number
sys_addr	device address given by system
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function erases the data in the chip. Function issues all required commands and polls for completion. If BEOp is attempted on the protected area, the function returns SLLD_OK but erase operation is not executed.

Function Name	slld_WRSROp
Purpose	Performs a Write Status Register Operation
Parameters	
device_num	device number
data_buf	variable containing data to program
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function writes a new value to status register. Function issues all required commands and polls for completion. If WRSROp is attempted with status register (or part of it) protected, the function returns SLLD_OK but status register is not updated.

Function Name	slld_WRROp
Purpose	Writes to Registers.
Parameters	
device_num	device number
status_val	variable containing data to program to the status register
config_val	variable containing data to program to the configuration register
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the WRR command to SPI Flash. Function issues all required commands and polls for completion. If WRROp is attempted with status/configuration registers protected (or part of them), the function returns SLLD_OK but the registers are not updated.

Function Name	slld_WASPOp
Purpose	Writes to ASP register.
Parameters	
device_num	device number
asp_val	variable containing data to program to the ASP register
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the WASP command to SPI Flash. Function issues all required commands and polls for completion.

Function Name	slld_WBNKOp
Purpose	Writes to bank addressing register.
Parameters	
device_num	device number
bnk_val	variable containing data to program to the bank addressing register
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the WBNK command to SPI Flash. Function issues all required commands and polls for completion.

Function Name	slld_WABTOp
Purpose	Writes to Auto Boot register.
Parameters	
device_num	device number
abt_val	variable containing data to program to the Auto Boot register
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the WABT command to SPI Flash. Function issues all required commands and polls for completion.

Function Name	slld_WPWDOP
Purpose	Writes to the password.
Parameters	
device_num	device number
target	variable containing data to program to the password
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the WPWD command to SPI Flash. Function issues all required commands and polls for completion.

Function Name	slld_BlockProtectOp
Purpose	Performs a Block Protect Operation
Parameters	
device_num	device number
bpb_value	value of block protect bits. Valid value for bpb_value is: 0x0 - 0x3 : for S25FL001D, S25FL002D 0x0 - 0x7 : for S25FL004D *For detail, please refer to data sheet of target device.
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	Function sets Block Protect bits to protect specified memory area. Function issues all required commands and polls for completion.

Function Name	slld_PPB_PGOp
Purpose	Performs a PPB Programming Operation
Parameters	
device_num	device number
sys_addr	device address given by system
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function programs the PPB at the specified location and polls for completion.

Function Name	slld_DYB_PGOp
Purpose	Performs a DYB Programming Operation
Parameters	
device_num	device number
sys_addr	device address given by system
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function programs the DYB at the specified location and polls for completion.

Function Name	slld_GBLOp
Purpose	Performs a Global IBL lock Operation
Parameters	
device_num	device number
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Global IBL lock command to SPI Flash, and then polls for completion.

Function Name	slld_GBULOp
Purpose	Performs a Global IBL unlock Operation
Parameters	
device_num	device number
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Global IBL unlock command to SPI Flash, and then polls for completion

Function Name	slld_SPRPOp
Purpose	Performs a Set Pointer Region Protection Operation
Parameters	
device_num	device number
sys_addr	device address given by system
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the SPRP command to SPI Flash, and then polls for completion.

Function Name	slld_BlockEraseOp
Purpose	Performs a Block Erase Operation
Parameters	
device_num	device number
sys_addr	device address given by system
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Block Erase command to SPI Flash, and then polls for completion.

Function Name	slld_BE32KBOp
Purpose	Performs a 32KB Block Erase Operation for FLK device
Parameters	
device_num	device number
sys_addr	device address given by system
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function sends a 32-KB Block erase command to FLK device and polls for completion.

Function Name	slld_WRAR_Op
Purpose	Performs a Write any register Operation
Parameters	
device_num	device number
reg_addr	register address given by system
data_buf	variable containing data to program
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the write any register command and write 1-byte.

Function Name	slld_PPBP_Op
Purpose	Performs a PPB program Operation
Parameters	
device_num	device number
sys_addr	device address given by system
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the PPB Program command to SPI Flash and programs it, then polls for completion.

Function Name	slld_DYBWR_Op
Purpose	Performs a DYB write Operation
Parameters	
device_num	device number
sys_addr	device address given by system
data_buf	variable containing data to program
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the DYB write command to SPI Flash and programs it, then polls for completion.

Function Name	slld_IRPPOp
Purpose	Performs a write to IRP register Operation
Parameters	
device_num	device number
irp_val	variable containing data to program to the IRP register
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the write IRP register command to SPI Flash and programs it, then polls for completion.

Function Name	slld_SECRPOp
Purpose	Performs a Security Region program Operation
Parameters	
device_num	device number
sys_addr	device address given by system
program_buf	variable containing data to program
len_in_bytes	number of bytes
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the write IRP register command to SPI Flash and programs it, then polls for completion.

Function Name	slld_SECRPOp
Purpose	Performs a Security Region program Operation
Parameters	
device_num	device number
sys_addr	device address given by system
program_buf	variable containing data to program
len_in_bytes	number of bytes
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Security Region program command to SPI Flash and programs it, then polls for completion.

Function Name	slld_SECREOp
Purpose	Performs a Security Region erase Operation
Parameters	
device_num	device number
sys_addr	device address given by system
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Secure Region erase command to SPI Flash, and then polls for completion.

Function Name	slld_HBEOp
Purpose	Performs a Half Block erase Operation
Parameters	
device_num	device number
sys_addr	device address given by system
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Half Block erase command to SPI Flash, and then polls for completion.

Function Name	slld_CEOp
Purpose	Performs a Chip erase Operation
Parameters	
device_num	device number
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Chip erase command to SPI Flash, and then polls for completion.

Function Name	slld_CE1Op
Purpose	Performs an Chip erase Operation with alternative instruction
Parameters	
device_num	device number
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Chip erase command to SPI Flash, and then polls for completion.

Function Name	slld_IBLOp
Purpose	Performs a IBL lock Operation
Parameters	
device_num	device number
sys_addr	device address given by system
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the IBL lock command to SPI Flash, and then polls for completion.

Function Name	slld_IBULOp
Purpose	Performs a IBL unlock Operation
Parameters	
device_num	device number
sys_addr	device address given by system
dev_status_ptr	Pointer to the device status value after polling end
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the IBL unlock command to SPI Flash, and then polls for completion.

Function Name	slld_DataIntgChkOp
Purpose	Performs a data integrity check Operation
Parameters	
device_num	device number
start_addr	start address given by system
end_addr	end address given by system
dev_status_ptr	Pointer to the device status value after polling end
target	Pointer to CRC result buffer, the buffer should be 4 bytes
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the DIC command for the given start address to end address, polls for completion, and returns the CRC value.

Function Name	<code>slld_SecEraseCntOp</code>
Purpose	Performs a sector erase count Operation
Parameters	
<code>device_num</code>	device number
<code>sys_addr</code>	device address given by system
<code>dev_status_ptr</code>	Pointer to the device status value after polling end
<code>target</code>	Pointer to sector erase count result buffer, the buffer should be 3 bytes
Return Values	<code>SLLD_OK</code> , <code>SLLD_E_DEVICE_SOFTWARE_PROTECTED</code> or <code>SLLD_E_HAL_ERROR</code>
Details	This function issues the SEC command for the given sector address, polls for completion, and returns the count value.

Function Name	<code>slld_ECCCheckOp</code>
Purpose	Performs a ECC error count check Operation
Parameters	
<code>device_num</code>	device number
<code>ecc_status</code>	Pointer to ECC status buffer, buffer should be 1 byte
<code>error_count</code>	Pointer to error count buffer, buffer should be 2 bytes
<code>error_address</code>	Pointer to error address buffer, buffer should be 4 bytes
Return Values	<code>SLLD_OK</code> , <code>SLLD_E_DEVICE_SOFTWARE_PROTECTED</code> or <code>SLLD_E_HAL_ERROR</code>
Details	This function reads the ECC counter and returns the ECC status, error count, and address of the data unit with ECC error. Then reset the error counts.

3.2 Command Functions

Function Name	slld_ReadCmd
Purpose	Reads from SPI Flash.
Parameters	
device_num	device number
sys_addr	device address given by system
target	variable in which to store read data
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Read command to SPI Flash and reads data from the array. Data size is specified by len_in_bytes.

Function Name	slld_Read_4BCmd
Purpose	Reads from SPI Flash using 4-bytes addressing scheme.
Parameters	
device_num	device number
sys_addr	device address given by system
target	variable in which to store read data
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Read command to SPI Flash and reads data from the array using 4-bytes addressing scheme. Data size is specified by len_in_bytes.

Function Name	slld_Fast_ReadCmd
Purpose	Fast_Read from SPI Flash.
Parameters	
device_num	device number
sys_addr	device address given by system
target	variable in which to store read data
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Fast_Read command to SPI Flash and reads data from the array. Data size is specified by len_in_bytes.

Function Name	slld_Fast_Read_4BCmd
Purpose	Fast_Read from SPI Flash using 4-bytes addressing scheme.
Parameters	
device_num	device number
sys_addr	device address given by system
target	variable in which to store read data
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Fast_Read command to SPI Flash and reads data from the array using 4-bytes addressing scheme. Data size is specified by len_in_bytes.

Function Name	slld_DualIOReadCmd
Purpose	Reads from SPI Flash in Dual I/O mode.
Parameters	
device_num	device number
sys_addr	device address given by system
target	variable in which to store read data
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Dual I/O Read command to SPI Flash and reads data from the array. Data size is specified by len_in_bytes.

Function Name	slld_DualIORead_4BCmd
Purpose	Reads from SPI Flash in Dual I/O mode using 4-bytes addressing scheme.
Parameters	
device_num	device number
sys_addr	device address given by system
target	variable in which to store read data
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Dual I/O Read command to SPI Flash and reads data from the array using 4-bytes addressing scheme. Data size is specified by len_in_bytes.

Function Name	slld_DualIOHPReadCmd
Purpose	Reads from SPI Flash in Dual I/O high performance mode.
Parameters	
device_num	device number
sys_addr	device address given by system
target	variable in which to store read data
mode	read mode
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Dual I/O High Performance Read command to SPI Flash and reads data from the array. Data size is specified by len_in_bytes.

Function Name	slld_DualIOHPRead_4BCmd
Purpose	Reads from SPI Flash in Dual I/O high performance mode using 4-bytes addressing scheme.
Parameters	
device_num	device number
sys_addr	device address given by system
target	variable in which to store read data
mode	read mode
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Dual I/O High Performance Read command to SPI Flash and reads data from the array using 4-bytes addressing scheme. Data size is specified by len_in_bytes.

Function Name	slld_QuadIOReadCmd
Purpose	Reads from SPI Flash in Quad I/O mode.
Parameters	
device_num	device number
sys_addr	device address given by system
target	variable in which to store read data
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Quad I/O Read command to SPI Flash and reads data from the array. Data size is specified by len_in_bytes.

Function Name	sliid_QuadIORead_4BCmd
Purpose	Reads from SPI Flash in Quad I/O mode using 4-bytes addressing scheme.
Parameters	
device_num	device number
sys_addr	device address given by system
target	variable in which to store read data
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Quad I/O Read command to SPI Flash and reads data from the array using 4-bytes addressing scheme. Data size is specified by len_in_bytes.

Function Name	sliid_QuadIOHPReadCmd
Purpose	Reads from SPI Flash in Quad I/O high performance mode.
Parameters	
device_num	device number
sys_addr	device address given by system
target	variable in which to store read data
mode	read mode
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Quad I/O High Performance Read command to SPI Flash and reads data from the array. Data size is specified by len_in_bytes.

Function Name	sliid_QuadIOHPRead_4BCmd
Purpose	Reads from SPI Flash in Quad I/O high performance mode using 4-bytes addressing scheme.
Parameters	
device_num	device number
sys_addr	device address given by system
target	variable in which to store read data
mode	read mode
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Quad I/O High Performance Read command to SPI Flash and reads data from the array using 4-byte addressing scheme. Data size is specified by len_in_bytes.

Function Name	slld_Read_IDCmd
Purpose	Reads ID from SPI Flash
Parameters	
device_num	device number
target	variable in which to store read data
Return Values	SLLD_OK or SLLD_E_HAL_ERROR
Details	This function issues the Read_ID command to SPI Flash and reads the device ID

Function Name	slld_RDIDCmd
Purpose	Reads Identification from SPI flash
Parameters	
device_num	device number
target	variable in which to store read data
Return Values	SLLD_OK or SLLD_E_HAL_ERROR
Details	This function issues the RDID command to SPI Flash and reads the identification. Note the identification consists of 3 bytes (manufacturer identification byte, memory type byte, and memory capacity byte.)

Function Name	slld_Read_IdentificationCmd
Purpose	Reads Identification from SPI flash
Parameters	
device_num	device number
target	variable in which to store read data
addr	address offset for the command
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Read-ID command to SPI Flash and reads the identification. Note the identification consists of 2 bytes (manufacturer identification byte and Device ID.)

Function Name	slld_RDSRCmd
Purpose	Reads from Status Register.
Parameters	
device_num	device number
target	variable in which to store read data
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the RDSR command to SPI Flash and reads the value of status register.

Function Name	slld_SRSTCmd
Purpose	Writes software reset to the flash.
Parameters	
device_num	device number
Return Values	SLLD_OK or SLLD_E_HAL_ERROR
Details	This function issues the SRST command to the SPI Flash.

Function Name	slld_RASPCmd
Purpose	Reads from ASP Register.
Parameters	
device_num	device number
target	variable in which to store read data
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the RASP command to SPI Flash and reads the value of the ASP register.

Function Name	slld_RBNKCmd
Purpose	Reads from bank addressing Register.
Parameters	
device_num	device number
target	variable in which to store read data
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the RBNK command to SPI Flash and reads the value of the bank addressing register.

Function Name	slld_RABTCmd
Purpose	Reads from Auto Boot Register.
Parameters	
device_num	device number
target	variable in which to store read data
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the RABT command to SPI Flash and reads the value of the Auto Boot register.

Function Name	slld_RECCCCmd
Purpose	Reads from ECC Register.
Parameters	
device_num	device number
sys_addr	device address given by system
target	variable in which to store read data
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the RECC command to SPI Flash and reads the value of the ECC register per cache-line.

Function Name:	slld_RPWDcmd
Purpose:	Reads the Password.
Parameters:	
device_num	device number
target	variable in which to store read data
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the RPWD command to SPI Flash and reads the value of the password.

Function Name	slld_RCRCmd
Purpose	Reads from Configuration Register.
Parameters	
device_num	device number
target	variable in which to store read data
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the RCR command to SPI Flash and reads the value of configuration register.

Function Name	slld_WRENCmd
Purpose	Writes the Write Enable command.
Parameters	
device_num	device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the WREN command to SPI Flash.

Function Name	slld_WRDCmd
Purpose	Writes the Write Disable command.
Parameters	
device_num	device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the WRDI command to SPI Flash.

Function Name	<code>slld_WRSRCmd</code>
Purpose	Write to Status Register.
Parameters	
device_num	device number
data_buf	variable containing data to program
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the WRSR command to SPI Flash.

Function Name	<code>slld_WRRCmd</code>
Purpose	Writes to Registers.
Parameters	
device_num	device number
status_val	variable containing data to program to the status register
config_val	variable containing data to program to the configuration register
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the WRR command to SPI Flash.

Function Name	<code>slld_WASPCmd</code>
Purpose	Writes to ASP register.
Parameters	
device_num	device number
asp_val	variable containing data to program to the ASP register
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the WASP command to SPI Flash.

Function Name	sIId_WBNKCmd
Purpose	Writes to bank addressing register.
Parameters	
device_num	device number
bnk_val	variable containing data to program to the bank addressing register
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the WBNK command to SPI Flash.

Function Name	sIId_WABTCmd
Purpose	Writes to Auto Boot register.
Parameters	
device_num	device number
abt_val	variable containing data to program to the Auto Boot register
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the WABT command to SPI Flash.

Function Name	sIId_WPWDCmd
Purpose	Writes to password.
Parameters	
device_num	device number
target	variable containing data to program to the password
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the WPWD command to SPI Flash.

Function Name	<code>slld_PPCmd</code>
Purpose	Page Program.
Parameters	
<code>device_num</code>	device number
<code>sys_addr</code>	device address given by system
<code>data_buf</code>	variable containing data to program
<code>len_in_bytes</code>	number of bytes to program
Return Values	<code>SLLD_OK</code> , <code>SLLD_E_DEVICE_SOFTWARE_PROTECTED</code> or <code>SLLD_E_HAL_ERROR</code>
Details	This function issues the PP command to SPI Flash.

Function Name	<code>slld_PP_4BCmd</code>
Purpose	Page Program using 4-bytes addressing scheme.
Parameters	
<code>device_num</code>	device number
<code>sys_addr</code>	device address given by system
<code>data_buf</code>	variable containing data to program
<code>len_in_bytes</code>	number of bytes to program
Return Values	<code>SLLD_OK</code> , <code>SLLD_E_DEVICE_SOFTWARE_PROTECTED</code> or <code>SLLD_E_HAL_ERROR</code>
Details	This function issues the PP command to SPI Flash using 4-byte addressing scheme.

Function Name	slld_QPPCmd
Purpose	Quad I/O Page Program.
Parameters	
device_num	device number
sys_addr	device address given by system
data_buf	variable containing data to program
len_in_bytes	number of bytes to program
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the QPP command to SPI Flash.

Function Name	slld_QPP_4BCmd
Purpose	Quad I/O Page Program using 4-bytes addressing scheme.
Parameters	
device_num	device number
sys_addr	device address given by system
data_buf	variable containing data to program
len_in_bytes	number of bytes to program
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the QPP command to SPI Flash using 4-byte addressing scheme.

Function Name	slld_SECmd
Purpose	Sector Erase.
Parameters	
device_num	device number
sys_addr	device address given by system
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the SE command to SPI Flash.

Function Name	slld_SE_4BCmd
Purpose	Sector Erase using 4-bytes addressing scheme.
Parameters	
device_num	device number
sys_addr	device address given by system
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the SE command to SPI Flash using 4-byte addressing scheme.

Function Name	slld_ERS_SSPCmd
Purpose	Suspend sector erase operation.
Parameters	
device_num	device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the ERS_SSP command to SPI Flash.

Function Name	slld_ERS_RESCmd
Purpose	Resumes suspended sector erase operation.
Parameters	
device_num	device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the ERS_RES command to SPI Flash.

Function Name	slld_RCVRCmd
Purpose	Initiates recovery mode.
Parameters	
device_num	device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the RCVR command to SPI Flash.

Function Name	slld_RCSPCmd
Purpose	Suspends the Recovery mode.
Parameters	
device_num	device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the RCSP command to SPI Flash.

Function Name	slld_RCRSCmd
Purpose	Resumes the suspended Recovery mode.
Parameters	
device_num	device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the RCRS command to SPI Flash.

Function Name	slld_P4ECmd
Purpose	4KB Parameter Sector Erase.
Parameters	
device_num	device number
sys_addr	device address given by system
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the P4E command to SPI Flash.

Function Name	slld_P8ECmd
Purpose	8KB Parameter Sector Erase.
Parameters	
device_num	device number
sys_addr	device address given by system
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the P8E command to SPI Flash.

Function Name	slld_P8E_4BCmd
Purpose	8KB Parameter Sector Erase using 4-bytes addressing scheme.
Parameters	
device_num	device number
sys_addr	device address given by system
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the P8E command to SPI Flash using 4-byte addressing scheme.

Function Name	slld_BECmd
Purpose	Bulk (Chip) Erase.
Parameters	
device_num	device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the BE command to SPI Flash.

Function Name	slld_OTPPCmd
Purpose	Programs OTP area.
Parameters	
device_num	device number
sys_addr	device address given by system
data_buf	variable containing data to program
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the OTPP command to SPI Flash.

Function Name	slld_OTPRCmd
Purpose	Reads data from OTP region.
Parameters	
device_num	device number
sys_addr	device address given by system
target	variable in which to store read data
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the OTP Read command to SPI Flash and reads data from OTP region. Data size is specified by len_in_bytes.

Function Name	slld_SPCmd
Purpose	Software Protect (Deep power-Down).
Parameters	
device_num	device number
Return Values	SLLD_OK or SLLD_E_HAL_ERROR
Details	This function issues the DP command to SPI Flash.

Function Name	slld_RESCmd
Purpose	Exit Software Protection mode (Release from Deep Power-Down mode).
Parameters	
device_num	device number
Return Values	SLLD_OK or SLLD_E_HAL_ERROR
Details	This function issues the RES command to SPI Flash.

Function Name	slld_ClearStatusRegisterCmd
Purpose	Clears the status register.
Parameters	
device_num	device number
Return Values	SLLD_OK or SLLD_E_HAL_ERROR
Details	This function issues the CLSR command to SPI Flash.

Function Name	slld_PPB_PGCmd
Purpose	Program PPB.
Parameters	
device_num	device number
sys_addr	device address given by system
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the program PPB command to SPI Flash.

Function Name	slld_DYB_PGCmd
Purpose	Program DYB.
Parameters	
device_num	device number
sys_addr	device address given by system
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the program DYB command to SPI Flash.

Function Name	slld_PASSUCmd
Purpose	Password Unlock.
Parameters	
device_num	device number
data_buf	variable containing data to program
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the PASSU command to SPI Flash.

Function Name	slld_RSTCmd
Purpose	Software Reset
Parameters	
device_num	device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Software Reset command immediately following a RSTEN command initiates the software reset process.

Function Name	slld_RSTENCmd
Purpose	Software Reset Enable
Parameters	
device_num	device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Reset Enable command which required immediately before a Reset command (RST).

Function Name	slld_DPCmd
Purpose	Deep Power Down
Parameters	
device_num	device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Deep Power-down command to SPI Flash. This command sets the target device in deep power-down state to reduce power consumption.

Function Name	slld_PRLCmd
Purpose	Protection register lock (NVLOCK bit write).
Parameters	
device_num	device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the PRL command to SPI Flash.

Function Name	slld_PRRDCmd
Purpose	Protection register read.
Parameters	
device_num	device number
data_buf	variable containing data to program
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the PRRD command to SPI Flash.

Function Name	slld_SBLCmd
Purpose	Set Burst Length.
Parameters	
device_num	device number
wrapbit_buf	variable in which to store wrap bit data
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Set Burst Length command to SPI Flash.

Function Name	slld_MBRCmd
Purpose	Mode Bit Reset.
Parameters	
device_num	device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the MBR command to return the device from continuous high performance read mode back to normal standby awaiting any new command.

Function Name	slld_BlockEraseCmd
Purpose	Block Erase.
Parameters	
device_num	device number
sys_addr	device address given by system
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Block Erase command to SPI Flash. The Block Erase command sets all bits in the addressed 64 KB block to 1 (all bytes are FFh).

Function Name	slld_RDQIDCmd
Purpose	Read manufacturer ID in Quad All mode.
Parameters	
device_num	device number
target	variable in which to store read data
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the RDQID command to SPI Flash and read ID data.

Function Name	slld_RDSR2Cmd
Purpose	Read Status Register-2.
Parameters	
device_num	device number
target	variable in which to store read data
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the RDSR2 command to SPI Flash and read status register 2.

Function Name	slld_RDARCmd
Purpose	Read any device register.
Parameters	
device_num	device number
reg_addr	register address given by system
target	variable in which to store read data
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the read any register command and reads the requested data in 1-byte.

Function Name	slld_DLPRDCmd
Purpose	Read Data Learning register.
Parameters	
device_num	device number
data_buf	variable in which to store read data
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the read any register command and reads the requested data in 1-byte.

Function Name	slld_PNVDLRCmd
Purpose	Program NV Data Learning register.
Parameters	
device_num	device number
data_buf	variable in which to store read data
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the PNVDRL command to SPI Flash.

Function Name	slld_WVDLRCmd
Purpose	Write Volatile Data Learning register.
Parameters	
device_num	device number
data_buf	variable in which to store read data
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the WVDRL command to SPI Flash.

Function Name	slld_EPS_Cmd
Purpose	Sector Erase suspend.
Parameters	
device_num	device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the EPS command to SPI Flash.

Function Name	slld_EPR_Cmd
Purpose	Sector Erase resume.
Parameters	
device_num	device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the EPR command to SPI Flash.

Function Name	slld_4BAM_Cmd
Purpose	4-Byte Address Mode.
Parameters	
device_num	device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the 4BAM command to SPI Flash. Used for FSS devices.

Function Name	slld_PASSRDCmd
Purpose	Password Read.
Parameters	
device_num	device number
data_buf	variable in which to store read data
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the PASSRD command to SPI Flash and read password data.

Function Name	slld_PASSPCmd
Purpose	Program Password.
Parameters	
device_num	device number
data_buf	variable in which to store read data
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the PASSP command to SPI Flash.

Function Name	slld_WRENVCmd
Purpose	Write Enable for Volatile Status and Configure register.
Parameters	
device_num	device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the WRENV command to SPI Flash.

Function Name	slld_HBECmd
Purpose	Half Block Erase.
Parameters	
device_num	device number
sys_addr	device address given by system
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the HBE command to SPI Flash.

Function Name	slld_4HBECmd
Purpose	Half Block Erase 4 bytes addressing scheme.
Parameters	
device_num	device number
sys_addr	device address given by system
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the 4HBE command to SPI Flash.

Function Name	slld_4BECmd
Purpose	Block Erase 4 bytes addressing scheme.
Parameters	
device_num	device number
sys_addr	device address given by system
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the 4BE command to SPI Flash.

Function Name	slld_CECmd
Purpose	Chip erase.
Parameters	
device_num	device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the CE command to SPI Flash.

Function Name	slld_CE1Cmd
Purpose	Chip erase using alternate instruction.
Parameters	
device_num	device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the CE1 command to SPI Flash.

Function Name	slld_IBLRDCmd
Purpose	IBL read.
Parameters	
device_num	device number
sys_addr	device address given by system
target	variable in which to store read data
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the reading the state of each IBL bit protection.

Function Name	slld_4IBLRDCmd
Purpose	IBL read - 4 Bytes address.
Parameters	
device_num	device number
sys_addr	device address given by system
target	variable in which to store read data
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the reading the state of each IBL bit protection using 4-Byte address scheme.

Function Name	slld_IBLCmd
Purpose	IBL lock.
Parameters	
device_num	device number
sys_addr	device address given by system
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the IBL lock command to sets the selected IBL bit to "0" protecting each related sector / block.

Function Name	sIld_4IBLCmd
Purpose	IBL lock using 4 Bytes address scheme.
Parameters	
device_num	device number
sys_addr	device address given by system
Return Values	SLDD_OK, SLDD_E_DEVICE_SOFTWARE_PROTECTED or SLDD_E_HAL_ERROR
Details	This function issues the IBL lock command to sets the selected IBL bit to "0" protecting each related sector / block.

Function Name	sIld_IBULCmd
Purpose	IBL unlock.
Parameters	
device_num	device number
sys_addr	device address given by system
Return Values	SLDD_OK, SLDD_E_DEVICE_SOFTWARE_PROTECTED or SLDD_E_HAL_ERROR
Details	This function issues the IBL unlock command to sets the selected IBL bit to "1" unprotecting each related sector / block.

Function Name	sIld_4IBULCmd
Purpose	IBL unlock using 4 Bytes address scheme.
Parameters	
device_num	device number
sys_addr	device address given by system
Return Values	SLDD_OK, SLDD_E_DEVICE_SOFTWARE_PROTECTED or SLDD_E_HAL_ERROR
Details	This function issues the IBL unlock command to sets the selected IBL bit to "1" unprotecting each related sector / block.

Function Name	sIld_GBLCmd
Purpose	Global IBL lock.
Parameters	
device_num	device number
Return Values	SLDD_OK, SLDD_E_DEVICE_SOFTWARE_PROTECTED or SLDD_E_HAL_ERROR
Details	This function issues the global IBL lock command to sets all IBL bit to "0" protecting all sectors / blocks.

Function Name	slld_GBULCmd
Purpose	IBL unlock.
Parameters	
device_num	device number
Return Values	SLLD_OK, SLDD_E_DEVICE_SOFTWARE_PROTECTED or SLDD_E_HAL_ERROR
Details	This function issues the global IBL unlock command to sets all IBL bit to "1" unprotecting all sectors / blocks.

Function Name	slld_SPRPCmd
Purpose	Set Pointer Region Protection.
Parameters	
device_num	device number
sys_addr	device address given by system
Return Values	SLLD_OK, SLDD_E_DEVICE_SOFTWARE_PROTECTED or SLDD_E_HAL_ERROR
Details	This function issues the SPRP command to sets pointer region protection.

Function Name	slld_4SPRPCmd
Purpose	Set Pointer Region Protection - 4 Bytes address
Parameters	
device_num	device number
sys_addr	device address given by system
Return Values	SLLD_OK, SLDD_E_DEVICE_SOFTWARE_PROTECTED or SLDD_E_HAL_ERROR
Details	This function issues the 4SPRP command to sets pointer region protection.

Function Name	slld_DIORCmd
Purpose	Read flash using Dual IO.
Parameters	
device_num	device number
sys_addr	device address given by system
target	variable in which to store read data
modebit	the read mode to be passed to the device
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLDD_E_DEVICE_SOFTWARE_PROTECTED or SLDD_E_HAL_ERROR
Details	This function issues the dual I/O read command and reads the requested data.

Function Name	slld_4DIOCmd
Purpose	Read flash using 4-byte Dual IO.
Parameters	
device_num	device number
sys_addr	device address given by system
target	variable in which to store read data
modebit	the read mode to be passed to the device
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the 4-byte dual I/O read command and reads the requested data.

Function Name	slld_QIORCmd
Purpose	Read flash using Quad IO.
Parameters	
device_num	device number
sys_addr	device address given by system
target	variable in which to store read data
modebit	the read mode to be passed to the device
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the quad I/O read command and reads the requested data.

Function Name	slld_4QIORCmd
Purpose	Read flash using 4 Byte Quad IO.
Parameters	
device_num	device number
sys_addr	device address given by system
target	variable in which to store read data
modebit	the read mode to be passed to the device
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the 4-byte quad I/O read command and reads the requested data.

Function Name	<code>slld_DDRQIORCmd</code>
Purpose	Read flash using DDR Quad I/O.
Parameters	
<code>device_num</code>	device number
<code>sys_addr</code>	device address given by system
<code>target</code>	variable in which to store read data
<code>modebit</code>	the read mode to be passed to the device
<code>len_in_bytes</code>	number of bytes to read
Return Values	<code>SLLD_OK</code> , <code>SLLD_E_DEVICE_SOFTWARE_PROTECTED</code> or <code>SLLD_E_HAL_ERROR</code>
Details	This function issues the DDR quad I/O read command and reads the requested data.

Function Name	<code>slld_4DDRQIORCmd</code>
Purpose	Read flash using 4-byte DDR Quad I/O.
Parameters	
<code>device_num</code>	device number
<code>sys_addr</code>	device address given by system
<code>target</code>	variable in which to store read data
<code>modebit</code>	the read mode to be passed to the device
<code>len_in_bytes</code>	number of bytes to read
Return Values	<code>SLLD_OK</code> , <code>SLLD_E_DEVICE_SOFTWARE_PROTECTED</code> or <code>SLLD_E_HAL_ERROR</code>
Details	This function issues the 4-byte DDR quad I/O read command and reads the requested data.

Function Name	<code>slld_SECRRCmd</code>
Purpose	Security Region Read.
Parameters	
<code>device_num</code>	device number
<code>sys_addr</code>	device address given by system
<code>read_buf</code>	variable in which to store read data
<code>len_in_bytes</code>	number of bytes to read
Return Values	<code>SLLD_OK</code> , <code>SLLD_E_DEVICE_SOFTWARE_PROTECTED</code> or <code>SLLD_E_HAL_ERROR</code>
Details	This function issues the security region read command and reads the requested data.

Function Name	slld_SECRPCmd
Purpose	Security Region program.
Parameters	
device_num	device number
sys_addr	device address given by system
program_buf	data buffer
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the security region program command to SPI flash.

Function Name	slld_SECRECmd
Purpose	Security Region erase.
Parameters	
device_num	device number
sys_addr	device address given by system
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the security region erase command to SPI flash.

Function Name	slld_RUIDCmd
Purpose	Read Unique ID number.
Parameters	
device_num	device number
read_buf	variable in which to store read data
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the read UID command and reads the requested data.

Function Name	slld_BE32KBCmd
Purpose	Block Erase 32KB for FLK device.
Parameters	
device_num	device number
sys_addr	device address given by system
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the Block Erase 32KB command to SPI Flash.

Function Name	slld_WRARCmd
Purpose	Write any device register command.
Parameters	
device_num	device number
reg_addr	register address given by system
data_buf	variable containing data to program
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the write any register command to SPI Flash.

Function Name	slld_PPBP_Cmd
Purpose	PPB program.
Parameters	
device_num	device number
sys_addr	device address given by system
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the PPB Program command to SPI Flash and programs it. The command is followed by the 24 or 32-bit address, depending on the address length configuration CR2V[7].

Function Name	slld_DYBWR_Cmd
Purpose	DYB write.
Parameters	
device_num	device number
sys_addr	device address given by system
data_buf	variable containing data to program
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the DYB write command to SPI Flash.

Function Name	slld_ReadSFDPCmd
Purpose	Read Serial Flash Discoverable Parameter.
Parameters	
device_num	device number
sys_addr	device address given by system
read_buf	data buffer
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the read SDFP command to SPI Flash.

Function Name	slld_RDCR2Cmd
Purpose	Read from configuration register-2.
Parameters	
device_num	device number
target	variable in which to store read data
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the RDCR2 command to SPI Flash.

Function Name	slld_RDCR3Cmd
Purpose	Read from configuration register-3.
Parameters	
device_num	device number
target	variable in which to store read data
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the RDCR3 command to SPI Flash.

Function Name	slld_IRPRDCmd
Purpose	Read IRP Register.
Parameters	
device_num	device number
target	variable in which to store read data
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the IRPRD command to SPI Flash.

Function Name	slld_IRPPCmd
Purpose	Write to IRP Register.
Parameters	
device_num	device number
target	variable containing data to program to the IRP register
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the IRPP command to SPI Flash.

Function Name	slld_QPIENCmd
Purpose	Enter QPI
Parameters	
device_num	device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the QPIEN command to SPI Flash

Function Name	slld_QPIEXCmd
Purpose	Exit QPI.
Parameters	
device_num	device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the QPIEX command to SPI Flash.

Function Name	slld_4BENCmd
Purpose	Enter 4 byte Address Mode.
Parameters	
device_num	device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the 4BEN command to SPI Flash. This will sets the volatile Address Length bit (CR2V[0]) to 1 to change most 3-byte address commands to require 4 bytes of address.

Function Name	slld_4BEXCmd
Purpose	Exit 4 byte Address Mode.
Parameters	
device_num	device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the 4BEX command to SPI Flash. This will sets the volatile Address Length bit (CR2V[0]) to 0.

Function Name	slld_DORCmd
Purpose	Read flash using Dual Output.
Parameters	
device_num	device number
sys_addr	device address given by system
target	variable in which to store read data
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the dual output read command and reads the requested data.

Function Name	slld_4DORCmd
Purpose	Read flash using 4 Byte Dual Output
Parameters	
device_num	device number
sys_addr	device address given by system
target	variable in which to store read data
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the 4-byte dual output read command and reads the requested data.

Function Name	slld_QORCmd
Purpose	Read flash using Quad Output
Parameters	
device_num	device number
sys_addr	device address given by system
target	variable in which to store read data
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the quad output read command and reads the requested data

Function Name	slld_4QORCmd
Purpose	Read flash using 4 Byte Quad Output
Parameters	
device_num	device number
sys_addr	device address given by system
target	variable in which to store read data
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the 4-byte quad output read command and reads the requested data.

Function Name	slld_DICCmd
Purpose	Write data integrity check command to SPI Flash
Parameters	
device_num	device number
sys_addr	device address given by system
data_buf	variable in which to store start address and end address. Buffer size is 8 bytes. First 4 bytes is start address. The second 4 bytes is end address.
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues a data integrity check command to SPI Flash, the start and end address will be store buffer pointer.

Function Name	slld_SECCCmd
Purpose	Write sector erase count command to SPI Flash.
Parameters	
device_num	device number
sys_addr	device address given by system
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues a SEC command to SPI Flash

Function Name	slld_RUIDCmd
Purpose	Write sector erase count command to SPI Flash.
Parameters	
device_num	device number
read_buf	data buffer pointer to store UID, buffer size is 8 bytes
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues a RUID command to SPI Flash and read UID data.

Function Name	slld_CLECCCmd
Purpose	Write clear ECC register command to SPI Flash.
Parameters	
device_num	device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues a CLECC command to SPI Flash.

Function Name	slld_MB_4BEXCmd
Purpose	Issue the exit 4 byte address mode command to SPI Flash.
Parameters	
device_num	device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the 4BEX command to SPI Flash.

Function Name	slld_RICRCCmd
Purpose	Reads interface CRC data from SPI Flash
Parameters	
device_num	device number
data_buf	variable in which to store read data
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the interface CRC read command to SPI Flash and reads CRC data. Data size is 4 Bytes.

Function Name	slld_SDROPIRDCmd
Purpose	Reads from SPI Flash using 4-byte addressing scheme during SDR OPI mode.
Parameters	
device_num	device number
sys_addr	device address given by system
target	variable in which to store read data
modebit	the read mode to be passed to the device
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the SDR OPI read command to SPI Flash and reads data from the array using 4-byte addressing scheme. Data size is specified by len_in_bytes.

Function Name	slld_DDROPIRDCmd
Purpose	Reads from SPI Flash using 4-bytes addressing scheme during DDR OPI mode.
Parameters	
device_num	device number
sys_addr	device address given by system
target	variable in which to store read data
modebit	the read mode to be passed to the device
len_in_bytes	number of bytes to read
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function issues the DDR OPI read command to SPI Flash and reads data from the array using 4-byte addressing scheme. Data size is specified by len_in_bytes.

Function Name	slld_EnterQPIMode_Cfg
Purpose	Set flash to enter QPI mode through configure volatile register.
Parameters	
device_num	device number
dev_status_ptr	status pointer to store the status when polling
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function will configure CR2V to switch flash to QPI mode. For using this API, qpi_flag must be defined in HAL. This flag will indicate if the device is in SPI mode or QPI mode.

Function Name	slld_ExitQPIMode_Cfg
Purpose	Set flash to exit QPI mode through configure volatile register.
Parameters	
device_num	device number
dev_status_ptr	status pointer to store the status when polling
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function will configure CR2V to switch flash to QPI mode. For using this API, qpi_flag must be defined in HAL. This flag will indicate if the device is in SPI mode or QPI mode.

Function Name	slld_EnduraFlexCfg
Purpose	Configure EnduraFlex feature.
Parameters	
device_num	device number
dev_status_ptr	status pointer to store the status when polling
pntr0	pointer to register 0 buffer
pntr1	pointer to register 1 buffer
pntr2	pointer to register 2 buffer
pntr3	pointer to register 3 buffer
pntr4	pointer to register 4 buffer
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function will write the EnduraFlex Pointer address registers 4 to 0. The register buffer size is 2 bytes.

Function Name	slld_WriteNV_Cfg
Purpose	Write all the NV Configuration registers.
Parameters	
device_num	device number
data_buf	pointer to register data buffer
dev_status_ptr	status pointer to store the status when polling
SPI_Mode	flag for use SPI mode or QPI mode, 0 for SPI mode, 1 for QPI mode
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function will write the NV SR1 register and configuration registers CR1 to CR4 with the values provided by user in a 5-byte array.

Function Name	slld_EnterOPIMode
Purpose	Set flash to enter OPI mode through configure volatile register.
Parameters	
device_num	device number
mode	indicate the OPI mode, 0 for SPI, 1 for SDR OPI, 2 for DDR OPI
dev_status_ptr	status pointer to store the status when polling
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function will configure CR5V to switch flash to SDR OPI or DDR OPI mode. For using this API, opi_flag must be defined in HAL. This flag will indicate if the device is in SPI mode or SDR/DDR OPI mode.

Function Name	slld_ExitOPIMode
Purpose	Set flash to exit OPI mode through configure volatile register.
Parameters	
device_num	device number
dev_status_ptr	status pointer to store the status when polling
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function will configure CR5V to exit OPI mode. For using this API, opi_flag must be defined in HAL. This flag will indicate if the device is in SPI mode or SDR/DDR OPI mode.

3.3 Utility Functions

Function Name	slld_Poll
Purpose	Polls flash device for embedded operation completion.
Parameters	
device_num	device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function polls the flash device to determine when an embedded operation has finished.

Function Name	slld_StatusGet
Purpose	Determines Flash Status
Parameters	
device_num	device number
dev_status_ptr	variable to store device status
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function reads the status register of specified device and sets value of dev_status_ptr to the current device status (dev_busy, dev_program_error, dev_erase_error, dev_suspend or dev_not_busy.)

Function Name	slld_SoftwareProtectStatusGet
Purpose	Gets Flash Software protect Status.
Parameters	
device_num	device number
softwareprotect	
dev_status_ptr	variable to store device software protect status
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function gets the software protect status of the specified device from the variable stored in RAM.

Function Name	slld_GetDevNumFromAddr
Purpose	Helps user to get device number from address when target device with multiple chip select.
Parameters	
sys_addr	device address given by system
device_num	pointer to device number
Return Values	SLLD_OK, SLLD_E_DEVICE_SOFTWARE_PROTECTED or SLLD_E_HAL_ERROR
Details	This function can help the user to get the device number from the address when target device with multiple chip select. Before using this function, user must ensure the target device has multiple chip selects. The user must also modify BASE_ADDR_MASK and BASE_ADDR_SHIFT_BIT according to their own system configuration.

3.4

HAL Functions

Function Name	FLASH_READ
Purpose	Basic device read (one CS# cycle)
Parameters	
device_num	device number
command	Command byte to be written to the flash
sys_addr	System address to be read from
Data_buffer	Pointer to a data buffer where the read data will be stored
Number_Of_Bytes	Number of bytes to read
Return Values	SLLD_OK or SLDD_E_HAL_ERROR
Details	A call to the read function corresponds to a CS# cycle. The source code of this function must be adapted according to the system platform requirements.

Function Name	FLASH_WRITE
Purpose	Basic device write (one CS# cycle)
Parameters	
device_num	device number
command	Command byte to be written to the flash
sys_addr	System address to be written to
Data_buffer	Pointer to a data buffer containing data to be written
Number_Of_Bytes	Number of bytes to write
Return Values	SLLD_OK or SLDD_E_HAL_ERROR
Details	A call to the write function corresponds to a CS# cycle. The source code of this function must be adapted according to the system platform requirements.

Function Name	FLASH_INIT
Purpose	HAL initialization function
Parameters	Defined by user
Return Values	SLLD_OK or SLDD_E_HAL_ERROR
Details	This function is not necessary. It is not called by SLLD. It is only used to initialize the system controller and environment. The parameters of this function can be defined by the user.

Function Name	FLASH_DEINIT
Purpose	HAL de-initialization function
Parameters	Defined by user
Return Values	SLLD_OK or SLLD_E_HAL_ERROR
Details	This function is not necessary. It is not called by SLLD. It is only used to de-initialize the system controller and environment. The parameters of this function can be defined by the user.

Function Name	CMD_MODE_SWITCH
Purpose	Switch controller command mode between SPI/QPI/OPI
Parameters	mode command mode, 0 for spi, 1 for QPI, 2 for OPI SDR, 3 for OPI DDR
Return Values	SLLD_OK or SLLD_E_HAL_ERROR
Details	This function is required when using S25HS-T, S25HL-T, S28HS-T, and S28HL-T devices. It is used to switch the command mode on the host side.

Revision History



Document Revision History

Document Title: Cypress SPI NOR Flash Low-Level Driver User Guide

Document Number: 002-00997

Revision	ECN#	Issue Date	Origin of Change	Description of Change
**	–	10/05/2010	–	Initial version
*A	4969108	10/16/2015	MSWI	Updated in Cypress template
*B	5028171	11/26/2015	MSWI	Updated in User Guide template
*C	5211120	04/07/2016	PZHU	Updated API description to support FL-L devices
*D	6002165	02/06/2018	PEZH	Updated API description to support S25HS-T, S25HL-T, S28HS-T, and S28HL-T devices. Updated the template.
*E	6151674	04/24/2018	PEZH	Updated the title to "Cypress SPI NOR Flash Low-Level Driver User Guide"